



USER MANUAL



Inverter/charger

HP5542-AH1050P65C

Table of Contents

Important Safety Instructions	1
Disclaimers	6
1 General Information	7
1.1 Overview	7
1.2 Appearance	9
1.3 Naming rules	12
1.4 Connection diagram	12
2 Interface	14
2.1 Indicator	14
2.2 Buttons	15
2.3 Home page	15
2.4 Real-time data interface	19
2.4.1 PV	19
2.4.2 Utility	20
2.4.3 Inverter/charger	21
2.4.4 Load	21
2.4.5 Battery	22
2.4.6 Error code	23
2.5 Parameters setting	24
2.5.1 Parameters list	24
2.5.2 Battery work modes	44
2.5.3 Battery voltage control parameters	47
3 Single Installation	51
3.1 Attention	51
3.2 Wire size and circuit breaker	52
3.3 Mounting the inverter/charger	53

3.4 Wiring the inverter/charger	55
3.5 Operating the inverter/charger	60
4 Working Mode	62
4.1 Abbreviation	62
4.2 Battery mode	63
4.3 No battery mode	70
5 Protections	71
6 Troubleshooting	74
6.1 Battery faults	74
6.2 PV faults	75
6.3 Inverter faults	76
6.4 Utility faults	78
6.5 Load faults	79
6.6 Other faults for single inverter/charger	80
6.7 BMS faults	81
7 Maintenance	82
8 Technical Specifications	83
9 Dimensions	86
10 Appendices	87
10.1 Appendix1 Abbreviations index	87
10.2 Appendix 2 Battery state instruction	91

Important Safety Instructions

Please keep this manual for future reference.

This manual contains all the safety, installation, and operation instructions for the HP-AHP65C series inverter/charger (hereinafter referred to as "inverter/charger").

1. Explanation of symbols

To ensure the user's personal and property safety while using this product, relevant information is provided in the manual and highlighted with the following symbols. Please read the relevant texts carefully when you encounter the following symbols in the manual.



DANGER

Indicates a high-level hazard that, if not avoided, will result in serious injury or death.



WARNING

Indicates a medium-level hazard that, if not avoided, could result in death or serious injury.



CAUTION

Indicates a low-level hazard that, if not avoided, could result in minor or moderate injury.

NOTICE

Indicates an important reminder during the operation which, if ignored, may result in an equipment error alarm.

Tip

Indicates recommendation for reference.



Read through the user manual before any operations.

2. Requirements for professional and technical personnel

- Professionally trained.
- Familiar with related safety regulations of the electrical system.
- Read this manual carefully and master the related safety precautions.

3. Operations for professional and technical personnel

- Install the inverter/charger to a specified location.
- Conduct test operations for the inverter/charger.
- Operate and maintain the inverter/charger.

4. Safety precautions before installation



DANGER

- Keep the inverter/charger out of the reach of children.
- When installing the inverter/charger, end-users must evaluate whether the operation area exists arc danger.

NOTICE

- When receiving the inverter/charger, please check if there is any damage or scratches on the package and thoroughly verify the product model and the accessory list for completeness. If any anomalies (e.g., physical damage, model discrepancies, missing parts) are found, do not unpack the equipment. Please contact your authorized distributor immediately for instructions.
- When installing or moving the inverter/charger, follow the instructions in the manual.

5. Safety precautions for mechanical installation



DANGER

Before installation, confirm the inverter/charger has no electrical connection.

NOTICE

Ensure enough heat dissipation space for the inverter/charger before installation. Do not install the inverter/charger in flammable, explosive, dust accumulative, or other severe environments.

6. Safety precautions for electrical connection



DANGER

- Do not put the inverter/charger close to the flooded lead-acid battery because the spark in the terminals may ignite the hydrogen released by the battery.
- Both the utility input and AC output are of high voltage, do not touch the wiring to avoid electric shock.



WARNING

- Ensure all wirings are secure to prevent overheating due to loose connections.
- The inverter/charger shell should be connected to the ground, and the cross-sectional area of the wire connecting the ground terminal to the earth should not be less than 4mm².
- A fast-acting fuse or breaker should be used between the battery and inverter/charger; whose rated current should be twice of the inverter/charger rated input current.

NOTICE

- The AC output terminal is only for the load connection. Do not connect it to another power source or Utility. Otherwise, the inverter will be damaged. When it connects to the load, the inverter/charger needs to stop working.
- It is strictly forbidden to connect a transformer or a load with a surge power (VA) exceeding the overload power at the AC output port. Otherwise, the damage will be caused to the inverter/charger.

7. Safety precautions for inverter/charger operation



WARNING

- The inverter/charger generates much heat during operation with a high cabinet temperature. Do not touch the unit and keep it far away from the materials and devices that are sensitive to high temperature.
- When the inverter/charger is working, do not open the inverter/charger shell for any operation.
- When eliminating the fault that affects the safety performance of the inverter/charger, please first disconnecting the DC input circuit breaker and AC output circuit breaker, and turn off the inverter/charger switch. Then, operate it after the LCD is completely OFF.

8. Dangerous operations causing an electric arc, fire, or explosion

- Touch the uninsulated ends of potentially live cables.
- Touch the live wiring copper busbars, terminals, or internal components of the device.
- Loose connection of power cables.
- Accidental dropping of screws or other components inside the inverter/charger.
- Improper operations by untrained non-professional or technical personnel.

DANGER

Once an accident occurs, it must be handled by professionals. Improper operation would cause a more serious accident.

9. Safety precautions for stopping the inverter/charger

- Turn off the AC output and disconnect the utility input breakers. Then, turn off the DC switch.
- After the input and output wires are disconnected for ten minutes, the internal conductive modules can be touched.
- The inverter/charger does not contain repair parts internally. If any maintenance service is required, please get in touch with our after-sales service personnel.

CAUTION

Do not touch or open the shell after the inverter/charger is powered off within ten minutes.

10. Safety precautions for inverter/charger maintenance

- It is recommended to check the inverter/charger with testing equipment to ensure there is no voltage or current on the terminals and cables.
- When conducting the electrical connection and maintenance, post a temporary warning sign or put up barriers to prevent unrelated personnel from entering the electrical connection or maintenance area.
- Improper maintenance of the inverter/charger may cause personal injury or equipment damage;
- It is recommended to wear an antistatic wrist strap or avoid unnecessary contact with the circuit board.



CAUTION

The safety mark, warning label and rating plate on the inverter/charger should be clearly visible, not removed or covered.

11. Working temperature

- Ambient temperature: -20°C to $+55^{\circ}\text{C}$ (when the working temperature exceeds 35°C , the charging power and load power will be reduced appropriately.)
- Storage temperature: -25°C to $+60^{\circ}\text{C}$ (No sharp temperature changing)
- Relative humidity: $< 100\%$ (Non-condensing)
- Altitude: $< 4,000$ meters (If the altitude exceeds 2,000 meters, the actual output power is reduced appropriately.)

Disclaimers

The warranty does not apply to the following conditions:

- Damage caused by improper use or inappropriate environment (such as the flammable, explosive, dust accumulative, or other severe environments).
- The actual current/voltage/power exceeds the limit value of the inverter/charger.
- Damage caused by working temperature exceeding the rated range.
- Arc, fire, explosion, and other accidents caused by failure to follow the inverter/charger stickers or manual instructions.
- Unauthorized dismantling or attempted repair.
- Damage caused by force majeure such as lightning, power grid surges, floods, earthquakes, etc.
- Damage occurred during transportation or handling.

1 General Information

1.1 Overview

The HP-AHP65C series is an IP65 high protection level product. It supports utility charging, oil generator charging, solar charging, utility output, inverter output, and energy management. It supports parallel operation for multiple units (12 units in standard application, more than 12 units need to be customized) in single phase and three phase, with 220VAC single phase or 380VAC three phase AC output.

Advanced DSP chip with its control algorithm ensures high response speed, reliability, and conversion efficiency. Meanwhile, Three-stage charging method (Bulk Charging, Constant Charging, and Float Charging) are adopted to ensure battery safety. The 3.5-inch lattice LCD screen shows the operational status and full parameters.

The communication interface with the standard Modbus protocol allows end-users to expand their applications and is suitable for different monitoring requirements. The new optimized MPPT tracking technology can fast-track the PV array's max. power point in various situations and obtain the maximum energy in real time. Two PV input (connect separately or connect in parallel) is supported, which improves the PV utilization.

Adopting the advanced control algorithm, the AC to DC charging process brings the full digital PFC and dual closed-loop voltage-current control. It enables the input power factor close to 1 and improves the control accuracy. The fully smart digital DC to AC inverting process adopts the advanced SPWM technology, and converts the DC power to AC power (a pure sine wave). It is suitable for household appliances, power tools, industrial equipment, audio systems, and other electronics.

Customers can achieve efficient energy utilization by flexibly using solar energy or utility power via customized settings. This high-quality product ensures stable power supply and is suitable for hybrid power generation systems that combine solar, utility, and oil engine, it meets outdoor power supply requirements in harsh environments such as salt spray, dust, moisture and fog.

Features

- IP65 high protection level fits in harsh environments such as salt spray, dust, moisture and fog
- Pure sine wave output
- Support battery or non-battery mode
- Lithium battery communication port to perform the safe charging and discharging
- Lithium battery self-activation
- Parallel operation in single phase or three phase for 12 units in standard application⁽¹⁾
- PFC technology reduces the demand on the power grid capacity

- Advanced MPPT technology, with maximum energy conversion efficiency higher than 99.5%
- Some models support two PV inputs to improve PV utilization⁽²⁾
- Supporting charging from multiple types of generators⁽³⁾
- Total battery charging/discharging current settings to be compatible with different batteries
- Maximum utility charging current settings to flexibly configure utility charging power
- With the function of historical data recording⁽⁴⁾, up to 25,000 records. Upon reaching full capacity, the storage chip sectors (4,096 records per sector) are cyclically overwritten. The interval for recording historical data is configurable
- Multiple LED indicators show system status in real-time
- One-button control of AC output
- The 3.5-inch touchable color LCD for better status monitoring in real-time
- RS485 communication interface with optional WiFi and Bluetooth modules for remote monitoring
- Comprehensive electronic protections
- Noise reduction design, with noise less than 45dB.
- -20°C to 55°C operating temperature range to meets more environment requirements

(1) If more than 12 units are connected in parallel, please contact our sales personnel for customization.

(2) Only the HP5542-AH1050P65C supports two PV inputs for single MPPT tracking or two parallel MPPTs tracking, and increasing the PV maximum input current. When two PV arrays are independently input, set the "PVMode" as "Single." When two PV arrays connected in parallel to one access to the inverter/charger (the PV terminals of the inverter/charger need to be paralleled externally), set the "PVMode" as "Parallel." When there is only one PV array, set the "PVMode" as "Single" (The "Parallel" mode is invalid).


(3) When connecting a non-inverter generator, the charging current may not reach the rated power. It is recommended to connect an inverter generator. And when using the generator, the "ACmode" needs to be set to "Oil." For specific settings, please refer to Subsection [2.5.1 Parameters list](#) > [5. System \(System parameter settings\)](#). To reduce the probability of overvoltage protection triggered by generator voltage waveform distortion when using the generator, it is recommended that the generator power is greater than 1.5 times the rated power of the inverter/charger.

(4) Each historical record includes: Year, Month, Day, Hour, Minutes, Seconds, PV Maximum Voltage (V), PV Power (W), Utility Voltage (V), Utility Current (A), Utility Frequency (Hz), Utility Power (W), Load Voltage (V), Load Current (A), Load Power (W), Inverter Frequency (Hz), Battery Voltage (V), Battery Current (A), Battery SOC (%), Battery Temperature (°C), PV

Module Temperature (°C), Transformer Temperature (°C), Maximum BAT Volt (V) and Minimum BAT Volt (V).

1.2 Appearance


- HP5542-AH1050P65C



No.	Instruction	No.	Instruction
1	Color LCD (see Chapter 2)	8	PV terminals
2	AC output port	9	Power switch
3	AC input port	10	Air hole

4	Parallel connection input interface ⁽¹⁾	11	RS485 communication port (USB-A 3.0, with isolation design) ⁽³⁾ , 5VDC/1.2A
5	Parallel connection output interface ⁽¹⁾	12	BMS port (RJ45, with isolation design) ⁽⁴⁾
6	Dry contact interface ⁽²⁾	13	USB port ⁽⁵⁾
7	Battery terminals	14	Cooling fan (HP5542-AH1050P65C)

(1) Pin definition for the parallel connection interface (USB-A 3.0 female connector):




Pin	Definition	Pin	Definition
1	NC	6	NC
2	PFS-BUS	7	NC
3	PS-GND	8	NC
4	CAN-L	9	NC
5	CAN-H		

(2) Dry contact specification: 1A@125VAC, 2A@30VDC.

Function: The dry contact interface is connected with the generator switch to turn on/off the generator.


(3) Connected with the RS485 communication port, an optional WiFi and Bluetooth modules can remotely control the inverter/charger. Pin definition for the RS485 communication port (USB-A 3.0 female connector):



Pin	Definition	Colour	Instruction
1	VBUS	Red	Power (5VDC/1.2A)
2	D-	White	Data transmission (D-)

3	D+	Green	Data transmission (D+)
4	GND	Black	Power ground
5	RS485-A1	Blue	RS485-A1 (to transfer data with cloud platform, APP, PC software, display screen and so on)
6	RS485-B1	Yellow	RS485-B1 (to transfer data with cloud platform, APP, PC software, display screen and so on)
7	GND2	Brown	Reserved
8	RS485-A2	Purple	Reserved
9	RS485-B2	Orange	Reserved

- (4) This inverter charger integrates BMS-Link module. Connect the lithium battery to the BMS communication port directly, and set the BMS protocol number, the BMS protocols of different lithium battery manufacturers can be converted into our company's standard ones, which can realize the communication between the inverter/charger and the BMS of other manufacturers. Pin definition for the BMS port (RJ45):



Pin	Definition	Pin	Definition
1	+5VDC	5	RS485-A
2	+5VDC	6	RS485-A
3	RS485-B	7	GND
4	RS485-B	8	GND

Tip

Please go to EPEVER official website to check or download the currently supported BMS manufacturers and the BMS parameters.

- (5) Update the inverter/charger's software after connecting the inverter/charger with a computer by a standard USB communication cable (**Note:** This port is reserved for engineer debugging only and is not available to the end-user).


1.3 Naming rules

HP 55 4 2 - AH 10 50 P65 C


- C: Color LCD
- Endosure: IP65
- PV maximum open-circuit voltage: Value*10V, such as "50" indicates "500V"
- PV maximum charging current: Value*10A, such as "10" indicates "100A"
- Asynchronous high frequency transformer
- Inverter output voltage: 1 indicates 110/120VAC; 2 indicates 220/230VAC
- Battery rated voltage: 2 indicates 24VDC; 4 indicates 48VDC
- Inverter rated power: Value*100W, such as "55" indicates "5,500W"
- HP Series

1.4 Connection diagram

- No battery mode



- Battery mode



NOTICE

- AC loads shall be determined according to the output power of the inverter/charger. The load exceeding the maximum output power may damage the inverter/charger.
- For different battery types, confirm the relevant parameters before power on.
- There are various types of oil generators with complex output situations. It is recommended to use the variable frequency oil generator. If a non-variable frequency oil generator is used, actual testing is required before use.

2 Interface






Tip The display screen can be viewed clearly when the angle between the end-user's horizontal sight and the display screen is within 90°. If the angle exceeds 90°, the information on the display screen cannot be viewed clearly.

2.1 Indicator


Indicator	Status	Description
PV	OFF	No PV input
	Solid green	PV normal
	Solid red	PV charging fault (PV1/PV2 overvoltage)
LOAD	OFF	No inverter output
	Solid green	Inverter, charging, and bypass are normal
	Solid red	Inverter fault (inverter overcurrent/overvoltage/undervoltage, output short-circuit, and over load)
GRID	OFF	No utility input
	Solid green	Utility normal
	Flashing green (0.5Hz)	Oil generator charging



















	Solid red	Utility charging fault (Utility overvoltage/ overcurrent/undervoltage/frequency abnormal)
RUN	Flashing green (0.5Hz)	Normal communication
	Solid red	Communication fault






2.2 Buttons










Buttons	Operation	Instruction
	Click	Exit the current interface and return to home page.
	Click	<p>Turn ON/OFF the load switch.</p> <p>Short press this button to pop up the following prompt message. Click ON/OFF to turn on/off the load switch. If set to "OFF", it will automatically return to "ON" after restarting.</p> 




2.3 Home page



No.	Instruction	
1		Displays the system time. Please set the system time correctly before use.
2		<p>Displays the battery discharge mode. For specific parameter settings, please refer to Subsection 2.5.1 Parameters list > 5. System (System parameter setting).</p> <p> PV > BP > BT</p> <p> PV > BT > BP</p> <p> BP > PV > BT</p>
3		<p>Displays the battery charge mode. For specific parameter settings, please refer to Subsection 2.5.1 Parameters list > 5. System (System parameter setting).</p> <p> means Solar mode;</p> <p> means Solar > Grid (Solar prior) mode;</p> <p> means Solar + Grid mode;</p> <p> means Grid > Solar (Grid prior) mode;</p>
4		Displays the current battery type. For specific parameter settings, please refer to Subsection 2.5.1 Parameters list > 5. System (System parameter setting) .
5		Parameter setting icon, click to enter the password input interface, and you can customize the system parameters after entering the password correctly. For specific operations, please refer to Subsection 2.5.1 Parameters list .
6		<ul style="list-style-type: none"> Display PV input voltage, PV input current. The direction of the arrow shows the energy flow state of the PV input (the number icon  or  on the line represents the current status of corresponding PV module 1 or 2) The arc  represents the percentage of the current PV generation power to the rated PV power generation. Display whether the PV module is working:  indicates that the PV module is working normally,  indicates that the PV

		<p>module is not working).</p> <ul style="list-style-type: none"> Display whether the MPPT of the current PV is working: "Relay: ON" means it is working normally, "Relay: OFF" means it is not working. <p>Click the PV icon to enter the PV real-time data interface. For specific operations, please refer to Subsection 2.4.1 PV.</p>
7		<ul style="list-style-type: none"> Display utility input voltage and utility input current. The direction of the arrow shows the energy flow state of the utility input. The arc  represents the percentage of current utility consumption power to rated AC output power. Display whether the utility is working normally:  indicates that the utility is working normally,  indicates that the utility is not working. Display the utility relay status: "Relay: ON" means the utility relay is connected, "Relay: OFF" means the utility relay is disconnected. <p>Click the utility icon to enter the utility real-time data. For specific operations, please refer to Subsection 2.4.2 Utility.</p>
8		<ul style="list-style-type: none"> Display the inverter/charger working status: "Inverter" indicates the inverter working status, "Grid" indicates the utility charging and utility bypass status). Display the parallel status icon (it will be displayed when there are more than 2 inverter/chargers with successful parallel communication, and will not be displayed on a single inverter/charger).★ <p>Click the inverter/charger icon to enter the inverter/charger information interface. For specific operations, please refer to Subsection 2.4.3 Inverter/charger.</p>

9		<ul style="list-style-type: none"> • Display the output voltage and output current of the load. The arrow direction indicates the energy flow state of the load. The arc  represents the percentage of the current load power to the rated load power. • Display the load status:  indicates that the load is on,  indicates that the load is off. • "Energy Used" indicates the total power consumption of the load (that is, the cumulative power consumption of the load since the inverter/charger was first turned on. If the data is cleared, it will be counted again). <p>Click the load icon to enter the load real-time interface. For specific operations, please refer to Subsection 2.4.4 Load.</p>
10		<ul style="list-style-type: none"> • Display the battery voltage and current in charging and discharging state. The arrow direction indicates the energy flow direction of the battery. • Display the working status of the battery:  indicates that the battery is charging and discharging normally,  indicates that working in battery-free mode. BMS indicates that the BMS communication is normal, BMS indicates that BMS fault occurs. If the BMS communication is abnormal or the BMS is not connected, this icon is not displayed, and the "BMS communication abnormal" fault is displayed. • Display battery SOC percentage value. The arc  represents the battery SOC percentage. • Display charging status: "Standby, Equalizing, Floating, and Boosting". • Display time: If it is charging or the remaining available discharging time is greater than 999 minutes, MAX is displayed. If the remaining available discharging time is less than or equal to 999 minutes, the specific number of minutes is displayed. <p>Click the battery icon to enter the battery real-time interface. For specific operations, please refer to Subsection 2.4.5 Battery.</p>
11		<p>The current system shows no fault.</p>

		The current system has a fault. Click on the icon to view the detailed real-time errors. For specific operations, please refer to Subsection 2.4.6 Error code.
12		 indicates turning on the 5V power supply of the inverter/charger's COM port, which can be connected to an external Bluetooth or WIFI module.

Note: When PV or utility is charging, the battery will be balanced by default at 06:00 on the 28th of each month (the date can be modified).

★ Parallel status icon name rule:



S (M) - 6


- > Number of parallel devices
- > M: Master device; S: Slave device
- > Phase: S (Single phase); A (A phase); B (B phase); C (C phase)





Note: The master and slave units are randomly defined.

2.4 Real-time data interface


2.4.1 PV





Touch  on the home page to enter the PV real-time data interface. The instructions of the interface are as follows:

Icon	Instruction
	<ol style="list-style-type: none"> 1. PV input voltage, PV input current 2. PV energy flow indication 3. PV real-time power <p>Note: If there is only one PV input, only one PV icon will be displayed here.</p>
	<ol style="list-style-type: none"> 1. Total PV generation (not displayed if there is only one PV input) 2. PV module temperature (temperature sampling by the PV internal heat sink (DC/DC heat sink))
	<p>Swipe up and down in this area to view all the settable parameters of the PV module.</p> <p>Refer to Subsection 2.5.1 Parameters list > 1. PV (PV parameter setting) to view the default values and setting range of the PV module.</p>
	<p>To slide up and down in this area to view the daily, monthly, annual and total power generation statistics of the PV module.</p>

2.4.2 Utility






Touch  on the home page to enter the Utility real-time data interface. The instructions of the interface are as follows:



Icon	Instruction
 <p>233.0 V 2.5 A 50.8 Hz 582.5 W</p>	<ol style="list-style-type: none"> 1. Utility input voltage, current, frequency 2. Utility energy flow instructions 3. Utility consumption power (the arrow points to the inverter/charger.)
<p>OVD : 265.0 V OVR : 255.0 V UVD : 175.0 V UVR : 185.0 V OFD : 70.0 Hz</p>	<p>Swipe up and down in this area to see all the settings of the Utility.</p> <p>Refer to Subsection 2.5.1 Parameters list > 3. Grid (Grid parameter setting) to view the default values and setting range of Utility parameters.</p>
<p>Today Consumption : 0.0 KWh This Month Consumption : 0.0 KWh This Year Consumption : 0.0 KWh Total Consumption : 0.0 KWh</p>	<p>Display the daily, monthly, yearly, and total electricity consumption statistics of the Utility.</p>


2.4.3 Inverter/charger





Touch  on the home page to enter the inverter/charger real-time data interface, and the interface will display the current product series, product model, SN, LCD PCB version, LCD firmware version and other product information. Click   to show other parameters.


2.4.4 Load














- On the home page, touch  to enter the load real-time data interface.
- Click **Fun** to display the Payload Real-time Data, Setting Parameters To Display page, and Parallel Real-Time Data page.
- Click **Page** to display all the information for the current page.

2.4.5 Battery






Touch  on the home page to enter the battery real-time data interface. The instructions of the interface are as follows:

Icon	Instruction
	<ol style="list-style-type: none"> Click  /  to turn to the next interface and display the Other Setting, BMS Data, Voltage Setting, and SOC Setting one by one. Click  to view all the information for the current page.
	<p>Display the SOC value of the battery. Click this icon to display the following BMS State interface, see Battery state instruction in Appendix 2 for details.</p>  <p>Click Up/Down to view other page, and click Back to return to the battery real-time data interface.</p>

	<ol style="list-style-type: none"> 1. Indicate whether the currently battery protocol supports high current.  indicates that the battery protocol does not support high current.  indicates that the protocol supports high current. 2. Indicate the setting value of BCCMode. VOL indicates that "BCCMode" is set to "VOL." SOC indicates that "BCCMode" is set to "SOC."
	<p>Displays real-time data of the battery: voltage, current, power, battery temperature, charging state.</p>
	<ol style="list-style-type: none"> 1. The number 23 indicates the currently battery protocol. 2. BMS indicates the set value of "BMS (BMS Enable)," gray indicates disable, and green indicates enable. 3. VOL indicates the setting value of "BMSVolt (BMS Voltage Control)," gray indicates disable, and green indicates enable. 4. CUR indicates the setting value of "BMSCurr (BMS Current Control)," gray indicates that the parameter is set to "Invalid", green indicates that the parameter is set to "BMS."

2.4.6 Error code




-  will be displayed on the home page when no fault occurs in the current system.
-  will be displayed on the home page when a fault occurs in the current system. Touch this icon to enter the real-time error code interface.
- Click **Fun** to display "Real-time Error Code, Historical Error Code" in order.
- Click **Clear** to clear the current fault list (the fault information will be cleared only after the


system fault is cleared; otherwise, the real-time fault list will not be cleared).



- If there are **Up** and **Down** on the current page, click the button to display the previous page and next page.


2.5 Parameters setting


2.5.1 Parameters list




1. Click  in the upper right corner of the home page to enter the password input interface.


2. Enter the correct password (default is 000000) on the input interface, and click  or  to enter the "Setting Options" interface.














- The parameter setting interface includes: PV (PV parameter setting), Charge (battery charge control parameter setting), Grid (Grid parameter setting), Load (Load parameter setting), System (System parameter setting), Others (Other parameters setting) and password setting.
- On the current interface, swipe up and down to select the parameter item to be set, and click it to enter the parameter setting interface.
- Click  to exit the current interface and return to the home page (after exiting in this way, if you enter the parameter setting interface again within 5 minutes, you do not need to enter the password; if it exceeds 5 minutes, you need to re-enter the password).

- Click  to safely exit the current interface to return to the home page (after exiting in this way, you will need to re-enter the password to enter the parameter setting interface).


1) PV (PV parameter setting)





Click **PV** on the setting interface to enter the PV parameter configuration. The instructions of the interface are as follows:

Icon	Instruction
	<p>Default values and settable ranges of PV parameters. Swipe up and down to view all the parameters on the current page.</p> <p> indicates that the parameter value can be customized (If the parameter is read-only, there is no  icon).</p>
	<p>Click to display the interface that can be set in addition to the current interface.</p> <p>Note: The PV configurable parameters are only on the current interface, and clicking the button does not respond.</p>
	<p>Click  button to display the parameter name, default value, maximum value and minimum value that can be set.</p>
	<p> x10.0  indicates the times of step size, which can be selected as 0.1 times, 0.5 times, 1 times, and 10 times. It varies with different parameters, the real display shall prevail.</p> <p>After the times of step size is set, click this button   to increase or decrease the current parameter.</p>



After the parameter setting is complete, click  to confirm the set value.

After all the parameters on the current page are set, click  to issue new parameter value, and the following message box will pop up:



Click **Save** to complete the parameter issue.

Default value and setting range for PV parameters as shown in the below:

Parameters	Default	User Define
Solar Setting Parameter		
OVP	500.0V	Read-only.
OVPR	480.0V	Read-only.
UVP	80.0V	User define: 80.0V to (Undervoltage Recovery Voltage minus 5V)
UVPR	100.0V	User define: 100.0 to 200.0V, or (Undervoltage Protection Voltage plus 5V) to 200.0V Note: Take the maximum value between 100.0V and (Undervoltage Protection Voltage plus 5V).
OTP	70.0℃	Read-only.
OTPR	65.0℃	Read-only.

2) Charge (Battery charge control parameter setting)



Click **Charge** on the parameter setting interface to enter the battery charge control parameter setting interface. The instructions of the interface are as follows:

Icon	Instruction
	<p>Default values and settable ranges for battery voltage/SOC control parameters. Swipe up and down to view all the parameters on the current page.</p> <p> indicates that the parameter value can be customized (If the parameter is read-only, there is no icon).</p>
	<p>Click to display the interface of Voltage Control Strategy and SOC Control Strategy.</p>

Note: For the content and operation methods of the parameter setting area on the right, please refer to the introduction of "1. PV (PV parameter setting)".

Default value and setting range for battery charge control parameters as shown in the below:

Parameters	Default	User Define
1. Voltage Control Strategy		
OVD	64.0V (48V system)	User define: (Overvoltage Recovery Voltage plus 0.1*N) ≤ Overvoltage Disconnect Voltage ≤ 16*N Note: N = Rated battery voltage/12.
CLV	60.0V (48V system)	User define: Equalization Charging Voltage < Charging Limit Voltage < Overvoltage Disconnect Voltage
OVR	60.0V (48V system)	User define: 42.8V ≤ Overvoltage Recovery Voltage ≤ (Overvoltage Disconnect Voltage minus 0.1*N) Note: N = Rated battery voltage/12.


ECV	58.4V (48V system)	User define: $21.4V \leq \text{Overvoltage Recovery Voltage} < \text{Overvoltage Disconnect Voltage} \text{ minus } 0.1*N$ Note: N = Rated battery voltage/12.
BCV	57.6V (48V system)	User define: $\text{Float Charging Voltage} \leq \text{Bulk Charging Voltage} \leq \text{Equalization Charging Voltage}$
FCV	55.2V (48V system)	User define: $\text{Bulk Voltage Recovery Voltage} < \text{Float Charging Voltage} \leq \text{Bulk Charging Voltage}$
BVR	52.8V (48V system)	User define: $\text{Low Voltage Recovery Voltage} < \text{Bulk Voltage Recovery Voltage} < \text{Float Charging Voltage}$
LVR	50.4V (48V system)	User define: $\text{Low Voltage Disconnect Voltage} < \text{Low Voltage Recovery Voltage} < \text{Bulk Voltage Recovery Voltage}$
UVWR	48.8V (48V system)	User define: $42.8 \leq \text{Undervoltage Alarm Recovery Voltage} \leq (\text{Overvoltage Recovery Voltage} \text{ minus } 0.1*N)$ Note: N = Rated battery voltage/12.
UVW	48.0V (48V system)	User define: $42.8V \leq \text{Undervoltage Alarm Voltage} \leq (\text{Undervoltage Alarm Recovery Voltage} \text{ minus } 0.1*N)$
LVD	44.4V (48V system)	User define: $\text{Discharging Limit Voltage} < \text{Low Voltage Disconnect Voltage} < \text{Low Voltage Recovery Voltage}$
DLV	42.4V (48V system)	Read-only.
AUX OFF	56.0V (48V system)	Under the charging mode of "Solar > Grid," the utility will stop charging the battery if the battery voltage exceeds this value. User define: $(\text{Auxiliary Charging ON Voltage} \text{ plus } 0.2*N) \leq \text{Auxiliary Charging OFF Voltage} \leq \text{Charging Limit Voltage}$ Note: N = Rated battery voltage/12.
AUX ON	51.0V (48V system)	Under the charging mode of "Solar > Grid," the utility will stop charging the battery if the battery voltage exceeds this value. User define: $(\text{Auxiliary Charging ON Voltage} \text{ plus } 0.2*N) \leq \text{Auxiliary Charging OFF Voltage} \leq \text{Charging Limit Voltage}$ Note: N = Rated battery voltage/12.

2. SOC Control Strategy

FCP	100%	<p>It takes effect after the "BCCMode" is set as "SOC." When the battery SOC is higher than or equals to this value, the inverter/charger will stop charging the battery.</p> <p>User define: (Full Charge Protection Recovery SOC plus 5%) to 100%, or 80% to 100%</p> <p>Note: Take the maximum value between (Full Charge Protection Recovery SOC plus 5%) and 80%.</p>
FCPR	95%	<p>It takes effect after the "BCCMode" is set as "SOC." When the battery SOC is lower than this value, the inverter/charger will charge the battery.</p> <p>User define: 60% to (Full Charge Protection SOC minus 5%)</p>
LPAR	40%	<p>It takes effect after the "BCCMode" is set as "SOC."</p> <p>It cannot be set separately (equals the "Discharging Protection Recovery SOC").</p>
LPA	25%	<p>It takes effect after the "BCCMode" is set as "SOC."</p> <p>User define: 10% to 35%, or 10% to (Discharging Protection Recovery SOC minus 5%)</p> <p>Note: Take the minimum value between (Discharging Protection Recovery SOC minus 5%) and 35%.</p>
DPR	40%	<p>It takes effect after the "BCCMode" is set as "SOC."</p> <p>User define: (Discharging Protection SOC plus 5%) to 60%, or 20% to 60%</p> <p>Note: Take the maximum value between (Discharging Protection SOC plus 5%) and 20%.</p>
DP	10%	<p>It takes effect after the "BCCMode" is set as "SOC." When the battery SOC is lower than this value, the battery will stop discharging.</p> <p>User define: 0 to 30%, or 0 to (Discharging Protection Recovery SOC minus 5%)</p> <p>Note: Take the minimum value between (Discharging Protection Recovery SOC minus 5%) and 30%.</p>
UAC ON	30%	<p>It takes effect after the "BCCMode" is set as "SOC."</p> <p>User define: 20% to 50%, or 20% to (Utility Auxiliary Charging OFF SOC minus 10%)</p> <p>Note: Take the minimum value between 50% and (Utility Auxiliary Charging OFF SOC minus 10%).</p>

UAC OFF	60%	It takes effect after the "BCCMode" is set as "SOC." User define: (Utility Auxiliary Charging ON SOC plus 10%) to 100%, or 40% to 100% Note: Take the maximum value between (Utility Auxiliary Charging ON SOC plus 10%) and 40%.
Set SOC	45%	Read-only. When the BMS is valid and the communication is normal, the real-time SOC value is automatically uploaded to the inverter/charger.

3) Grid (Grid parameter setting)



Click **Grid** on the parameter setting interface to enter the grid parameter setting screen. The instructions of the interface are as follows:

Icon	Instruction
	<p>Default values and settable ranges for grid setting parameters.</p> <p>Swipe up and down to view all the parameters on the current page.</p> <p> indicates that the parameter value can be customized (If the parameter is read-only, there is no icon).</p>
	<p>Click to display the interface that can be set in addition to the current interface.</p> <p>Note: The Grid configurable parameters are only for the current interface, and there is no response when you click the button.</p>

Note: For the content and operation methods of the parameter setting area on the right, please refer to the introduction of "1. PV (PV parameter setting)".

Default value and setting range for Grid parameters as shown in the below:

Parameter	Default	User Define
1. Grid Setting Parameter		
UOD	265.0V	User define: (Utility Overvoltage Recovery Voltage plus 10V) to 285.0V
UOR	255.0V	User define: 220.0V to (Utility Overvoltage Disconnect Voltage minus 10V)
ULVD	175.0V	User define: 90.0V to (Utility Low Voltage Recovery Voltage minus 10V)
ULVR	185.0V	User define: (Utility Low Voltage Disconnect Voltage plus 10V) to 220.0V
UOF	70.0Hz	<p>In the bypass state, when the actual utility input frequency is higher than this value, the inverter/charger will be switched to the inverter output state.</p> <p>User define: 52.0 to 70.0Hz, or (Utility Underfrequency Disconnect Frequency plus 0.5Hz) to 70.0Hz.</p> <p>Note: Take the maximum value between 52.0Hz and (Utility Underfrequency Disconnect Frequency plus 0.5Hz).</p>
UFD	40.0Hz	<p>In the bypass state, when the actual utility input frequency is lower than this value, the inverter/charger will be switched to the inverter output state.</p> <p>User define: 40.0Hz to 58.0Hz, or 40.0Hz to (Utility Overfrequency Disconnect Frequency minus 0.5Hz).</p> <p>Note: Take the minimum value between 58.0Hz and (Utility Overfrequency Disconnect Frequency minus 0.5Hz).</p>

4) Load (Load parameter setting)



Click **Load** on the parameter setting interface to enter the load parameter setting interface. The instructions of the interface are as follows:

Icon	Instruction
	<p>Default values and settable ranges for load setting parameters. Swipe up and down to view all the parameters on the current page.</p> <p> indicates that the parameter value can be customized (If the parameter is read-only, there is no icon).</p>
	<p>Click to display the interface that can be set in addition to the current interface.</p> <p>Note: The load configurable parameters are only for the current interface, and there is no response when you click the button.</p>



Note: For the content and operation methods of the parameter setting area on the right, please refer to the introduction of "1. PV (PV parameter setting)."

Default value and setting range for load parameters as shown in the below:

Parameter	Default	User Define
1. Load Setting Parameter		
INVOVL	220V	User define: 220V/230V
INVOFR	50Hz	<p>User define: 50Hz/60Hz</p> <p>Note: When the Utility power is connected and the Utility frequency is detected, the output frequency will be in accordance with the Utility frequency in the Utility bypass mode. For single inverter/charger, it will take effect immediately after the "INVOFR" is changed. For</p>

		the parallel connection, you must shut down the inverter/charger for 10s and then restart it for the modification to take effect (Enter into the "Load Setting Parameter" interface again to check if the change has been changed).
Load CL	42.0A	Read-only.
INVOP	265.0V	Read-only.
INVOPR	255.0V	Read-only.
TempUL	85.0℃	Read-only.
TempULR	80.0℃	Read-only.





5) System (System parameter setting)



Click **System** on the parameter setting interface to enter the system parameter setting interface. The instructions of the interface are as follows:

Icon	Instruction
	<p>Default values and settable ranges for system setting parameters.</p> <p>Swipe up and down to see all the parameters on the current page.</p> <p> indicates that the parameter value can be customized (If the parameter is read-only, there is no icon).</p>
	<p>Click to display the setting interface of "Battery Basic Properties, Advanced Battery Properties, Charge and Discharge Management, System Time Setting, and Local Parameters."</p>



Option-based parameter setting method: Click   to switch options, and a green dot flashes in front of the parameter to indicate that the current parameter is selected. Click  to confirm, and click  to issue new parameter value.

For details on setting numerical parameters, refer to the introduction of "1. PV (PV parameter setting)."


Default value and setting range for system parameters as shown in the below:

Parameter	Default	User Define
1. Battery Basic Properties		
Status	Have	User define: Have, NO Note: When the parameter value is changed (i.e., the value is changed from "Have" to "NO", or from "NO" to "Have"), the AC output will be cut off for about 3 seconds before resuming normal output.
BDCap	100.0 AH	User define: 10.0AH to 2400.0AH
BType	AGM	48V battery type: AGM, GEL, FLD, LFP15S, LFP16S, LNCM13S, LNCM14S
BRV	48 V	Read-only.
LBACC	100.0 A	User define: 5.0A to 100.0A for HP5542-AH1050P65C Namely, the maximum allowable charge current on battery side.
LBADC	250.0A	User define: 10.0A to 250.0A for HP5542-AH1050P65C Namely, the maximum allowable discharge current on battery side.
BECT	120 m	User define: 10minutes to 180 minutes
BECD	28D	User define: 1-28
BBCT	120m	User define: 10minutes to 180 minutes
BTCC	3 mV/°C/2V	User define: 0-9 Note: This option is reserved, which is invalid currently.

2. Advanced Battery Properties

Li PROT	Disable	User define: Disable, Enable Set this value as "Enable," the charge/discharge low temperature limit function is effective.
LTSCrg	0℃	User define: -20℃ to 0℃ When the environment or the battery temperature is lower than this value, the inverter/charger will stop charging the battery.
LTSDischrg	0℃	User define: -20℃ to 0℃ When the environment or the battery temperature is lower than this value, the inverter/charger will stop discharging.
BATT OTP	50.0℃	User define: (Battery Over Temperature Protection Recovery plus 5℃) to 60℃
BATT OTPR	45.0℃	User define: 30.0℃ to (Battery Over Temperature Protection minus 5℃)
Chrg	Enable	Read-only.
Dischrg	Enable	Read-only.
PCUP	Disable	User define: Disable, Enable Note: The parameter will only take effect when used in three phase. After the setting value was changed, the factory reset cannot be restored to the default value, it must be set by manually.
INVPSet	S	User define: S (Single), A (Phase A), B (Phase B), C (Phase C) Note: After the "INVPSet" is changed, must turn off the inverter/charger for 10 seconds before restarting. Enter into the "System > Advanced Battery Properties" interface again to check if the change has taken effect. After the setting value was changed, the factory reset cannot be restored to the default value, it must be set by manually.
UCD	5A	User define: 0A to 25A Note: The parameter will only take effect when used in three phase. When "PCUP (Phase Current

		Unbalance Protection)" is enabled, if current unbalance value between any two phases is higher than set value, the load output will be turned off automatically. After the setting value was changed, the factory reset cannot be restored to the default value, it must be set by manually.
3. Charge and Discharge Management		
BACC	100.0A	<p>Read-only.</p> <p>When the BMS is enabled and the communication between the inverter/charger and the lithium battery's BMS is normal, the "BACC" value is read from the BMS. Otherwise, the "BACC" value equals the setting value of "LBACC" after each power-on. If "LBACC" is changed without a subsequent restart, the "BACC" value remains the previous value of "LBACC".</p>
BADC	250.0A	<p>Read-only.</p> <p>When the BMS is enabled and the communication between the inverter/charger and the lithium battery's BMS is normal, the "BADC" value is read from the BMS. Otherwise, the "BADC" value equals the setting value of "LBADC" after each power-on. If "LBADC" is changed without a subsequent restart, the "BADC" value remains the previous value of "LBADC".</p>
UACC	100.0A	<p>User define: 5.0A to 100.0A.</p> <p>Namely, the maximum current at the battery end when the utility charges the battery.</p>
CMode	Solar + Grid	<p>User define: Solar (Solar only), Solar > Grid (Solar priority), Solar + Grid, Grid > Solar (Grid priority).</p> <p>Note: For detailed working modes, refer to Chapter 4 Working Mode.</p>
DMode	PV > BT > BP	<p>User define: PV > BP > BT (namely, PV > Bypass > Battery), PV > BT > BP (namely, PV > Battery > Bypass), BP > PV > BT (namely, Bypass > PV > Battery)</p> <p>Note: For detailed working modes differences, please refer to Chapter 4 Working Mode. The "Dmode (Discharge Mode)" is only effective when the "Cmode</p>



		<p>(Charging Mode)" is set as "Solar (Solar Only) " or "Solar > Grid (Solar priority)." If the "Cmode (Charging Mode)" is set as "Solar (Solar Only) " or "Solar > Grid (Solar priority)," during parallel operation, you should set the "Dmode (Discharge Mode)" as "PV>BT>BP (namely, PV>Battery>Bypass)," or "BP>PV>BT (namely, Bypass>Solar>Battery)" first.</p>
ACmode	Grid	<p>User define: Grid, Oil</p> <p>When the AC input is an oil generator, this parameter needs to be set to "Oil" to improve the charging capability. Note: If the AC input mode does not match the AC source of the actual input, the normal operation of the inverter/charger will be affected. After setting, restart the inverter/charger for the setting to take effect.</p>
PVMode	Single	<p>User define: Single, Parallel.</p> <p>When two PV arrays are independently input, the value shall be set to "Single."</p> <p>When two or more PV arrays are connected in parallel as a single input to the inverter/charger, the value needs to be set to "Parallel." The wiring diagram between the PV array and the inverter/charger is as follows:</p>  <p>Product with one PV input is "Single" by default (other PV modes are invalid).</p>
BCCMode	VOL	<p>User define: VOL (Voltage), SOC</p> <p>VOL: The battery voltage control parameters take effect after setting this value as "VOL."</p> <p>SOC: The SOC parameters take effect after setting this value as "SOC."</p> <p>Note: If "SOC" is selected, the battery needs to go through several full charge and discharge cycles, and the battery capacity must be set correctly.</p>



BMSProt	10	User define: 1-32 Note: Refer to the Lithium battery protocol file.
BMS	Disable	User define: Disable, Enable Set this value as "Enable," the inverter/charger will communicate with the battery normally.
BMSVolt	Enable	User define: Disable, Enable Set this value as "Enable," the BMS internal voltage control parameters will be automatically synchronized to the inverter/charger, and the inverter/charger will control the battery charging/discharging based on these parameters.
BMSCurr	Invalid	User define: Invalid, BMS Set this value as "Invalid," the inverter/charger controls the charge and discharge according to the value set on the LCD. Set this value as "BMS," the inverter/charger controls the charge and discharge according to the read BMS value.
BMSFail	DSP	User define: DSP, Disable DSP: The inverter/charger works according to the default mode and parameters. Disable: No charging and discharging, equivalent to standby mode.
BCM	Share	User define: Only, Share This parameter takes effect when the inverter/chargers are connected in parallel. If each inverter/charger is connected to the same battery pack, this value needs to be set to "Share." If each inverter/charger is connected to a separate battery pack, this value needs to be set to "Only."
4. System Time Setting		
5. Local Parameters		
LCD BRT	100%	User define: 50% to 100% It indicates the LCD brightness when operating the LCD.

TODelay	15S	User define: 6S to 60S After not operating the LCD, when the set "TODelay" time arrives, the LCD brightness decreases to the set "LCDSBRT" brightness.
LCDSBRT	50%	User define: 35% to 100% It indicates the LCD brightness after no operation for more than "TODelay" time.
SOT	30S	User define: 15-60S If the "Screen Timeout" is set to "ON", the LCD will turn off if time of no operation exceeds the "TODelay" time, and then exceeds the "SOT" time.
Com ID	1	User define: 1-240
Com BPS	115200bps	User define: 9600, 19200, 38400, 57600, 115200, 256000
DCT ON	44.0V (48V system)	User define: $9 \times N$ to (Dry Contract OFF Voltage minus $0.2 \times N$). Note: N = Rated battery voltage/12. When the battery voltage is lower than this value, the dry contact is connected.
DCT OFF	50.0V (48V system)	User define: (Dry Contract ON Voltage plus $0.2 \times N$) to $17 \times N$. Note: N = Rated battery voltage/12. When the battery voltage is higher than this value, the dry contact is disconnected.
Switch BMS	Enable	User define: Enable, Disable Under normal BMS communication, setting it to "Enable" allows charging, while setting it to "Disable" disallows charging. This parameter is invalid when BMS communication is abnormal.
Buzz	ON	User define: ON, OFF When set to "OFF", the buzzer does not go off even if the inverter/charger fault occurs.
LED	ON	User define: ON, OFF When set to "OFF", the LED indicator is off

HRI	60S	<p>User define: 1 second to 3,600 seconds</p> <p>Set the time interval for recording the historical data (only refers to the voltage, current and other data stored regularly, excluding the historical faults. These historical data can be exported by the Solar Guardian PC software or Website.)</p>
-----	-----	--

6) Others (Other parameters setting)




Click **Others** on the parameter setting interface to enter other parameters setting interface. Click   to switch the page and set the relevant parameters directly via the touch interface operation. The instructions of the interface are as follows:

Default value and setting range for other parameters as shown in the below:


Parameter	Default	User Define
Others		
Wireless	OFF	Read-only.
RTU Power (5V power supply for COM port)	ON	<p>User define: OFF, ON</p> <p>Turn on or off the 5V power supply of the inverter/charger COM port. The external Bluetooth or WIFI module can only work after it is set to "ON."</p>
Screen Timeout	ON	<p>User define: ON, OFF</p> <p>LCD backlight switch. Set to "ON," the LCD backlight will turn off after the "TODelay" time plus the "SOT" time has elapsed. Set to "OFF," the LCD backlight will remain on.</p>
Parameter Rest	Normal Mode	<p>User define: Normal Mode, Standby Mode</p> <p>To reset the settings parameters: select "Standby Mode," and then click the "Factory Reset" button to restore parts of</p>

		setting parameters to the default values (including password settings).
Low Power Mode	ECO Mode	<p>User define: ECO Mode, Normal Mode</p> <p>When set as "ECO Mode," the inverter/charger will enter the low power mode when certain conditions are met, such as no PV and utility, and the battery voltage drops to the low voltage disconnect voltage. When set as "Normal Mode," the inverter/charger will not enter the low power mode. If set to "Normal Mode," it will automatically return o "ECO Mode" after restarting.</p>
Manual Equalizer	--	<p>On the "Low Power Mode" interface, press the "Manual Equalizer" button to enter the manual equalization charging stage. If the inverter/charger is restarted at this time, it will automatically exit the manual equalization charging state.</p> <p>Note: This function has nothing to do with the selection of "Low Power Mode."</p>
DC Source Characteristic	PV Source	<p>User define: PV Source, DC Source</p> <p>When using a DC power supply instead of a PV array for power supply testing, set this parameter as "DC Source," otherwise the inverter/charger will not work properly. When set to "DC Source," the PV indicator will flash green; when set to "PV Source," the PV indicator will remain continuously green. If set to "DC Source," it will automatically return o "PV Source" after restarting.</p>
Initializing Records	--	<p>On the "DC Source Characteristic" interface, press the "Initializing Records" button and the progress bar pops up, the historical records and faults will be cleared after approximately 40 seconds.</p> <p>Note: This function has nothing to do with the selection of "DC Source Characteristic."</p>
Clear Statistical Power	Day Month Year	<p>User define: Day Month Year, Total Generation</p> <p>After selecting "Day Month Year" or "Total Generation", press the "Clear" button to clear the corresponding cumulative energy.</p>


7) Password setting




1. Click **Set Password** on the parameter setting page to enter the password modifying interface.



2. Enter the original password, the new password, and click **Update** to enter the interface of re-entering the password.



3. Enter the new password again and click **Update**.





4. Enter the new password and click **OK** to complete the password modifying and re-enter the parameter setting interface.


Note: The password can be changed to blank or any other digit no more than 6 digits. If the password is empty, no digits will be entered when changing the password.



8) Quick Setting Of BMS Parameters


Note: Enter the **Quick Setting Of BMS Parameters** interface without an administrator password, allowing for rapid configuration of BMS related parameters.





1. On the home page, click  in the upper-right corner.





2. Enter the password input interface, click  on the right interface, and then, click  to enter the "Quick Setting Of BMS Parameters" setting interface.



3. Select the "Battery Type" and "Protocol Number" and "SOC or VOL" according the actual situation, and click  to return to the password input page. When selecting "Battery Type" as "AGM, GEL or FLD," "SOC or VOL" is displayed as  by default, and the "Protocol Number" is hidden. Only when the "Battery Type" is selected as lithium battery will the "Protocol Number" appear.

After selecting the "Battery Type" as lithium battery, select the "Protocol Number" according to the lithium battery protocol table. **Note:** When the "Protocol Number" is set as "10," you shall set the parameter value of "BMS" as "Enable" in the system parameters settings page

After the "Protocol Number" is selected, "SOC or VOL" is displayed as  by default. You can manually set it as  according to the actual situations.

The above parameters can be modified separately on the administrator interface, please refer to Subsection 2.5.1 Parameters list for detailed settings.

Default value and setting range for BMS related parameters as shown in the below:

Parameter	Default	User define
Quick Setting Of BMS Parameters		
Battery Type	AGM	48V battery type: AGM, GEL, FLD, LFP15S, LFP16S, LNCM13S, LNCM14S
Protocol Number	10	User define: 1-32 Note: Refer to the Lithium battery protocol file.
SOC or VOL	VOL	VOL (Voltage), SOC

2.5.2 Battery work modes

The following table lists the recommended working mode and setting process for different application scenarios. According to your current battery status (such as whether it is a lithium-ion battery pack, whether it has BMS function, whether it has current control function at the end of charge and discharge, etc.), you can reasonably set the parameters to ensure that the battery works in the optimal performance, so as to ensure the safe operation of the system for a long time.


No.	Scenario	Recommended Working Mode	Setting Process
1	Non-lithium battery pack	The inverter/charger controls charging and discharging based on the LCD settings.	See Figure 1 “Setting process for non-lithium battery pack”
2	1. Lithium battery pack with BMS and current control function at the end of charge and discharge 2. Normal communication	The inverter/charger controls charging and discharging based on the read BMS values.	See Figure 2 “Setting process for lithium battery pack with BMS and current control function”


● Figure 1 “Setting process for non-lithium battery pack”



When the system adopts non-lithium battery packs (such as AGM, GEL, or FLD batteries), follow the flowchart below to set parameters correctly. The inverter/charger will control charging and discharging based on the LCD settings.


LCD	Parameters	Define
Battery Basic Properties	BDCap (Battery Design Capacity)	Set according to the actual battery type.
	BType (Battery Type)	
Charge and Discharge Management	BCCMode (Battery Charging Control Mode)	To set as “VOLT” or “SOC.” And then set the battery voltage control parameters or SOC control parameters.




1. Click  in the upper right corner on the home page to enter the password input interface.





2. Enter the correct password (by default 000000) on the input interface, and click  or  to enter the "Setting Options" interface.





3. Slide up and down on the current interface, and click **System** to enter the system parameter setting interface.



4. Depending on the battery actually used, set **BDCap** and **BType**. After the settings are complete, click  to issue new parameter value.





5. Click  to switch to the "Charge and Discharge Management" interface, and set **BCCMode** to "VOL" or "SOC". After the settings are complete, click  to issue new parameter value.


● Figure 2 "Setting process for lithium battery pack with BMS and current control function"



When the system adopts a lithium battery pack with BMS and current control function at the end of charge and discharge, and the lithium battery pack can communicate with the inverter/charger normally, follow the flowchart below to set parameters correctly. The inverter/charger controls charging and discharging based on the read BMS values.


LCD	Parameters	Define
Battery Basic Properties	BType (Battery Type)	Set it according to the battery you are actually using. Note: The battery type must be selected as lithium battery, otherwise the lithium battery data cannot be read.
Charge and Discharge Management	BCCMode (Battery Charging Control Mode)	To set as "VOLT" or "SOC." And then set the battery voltage control parameters or SOC control parameters..
	BMSProt (BMS Protocol)	Set the settings according to the actual battery protocol number used.
	BMS (BMS Enable)	Enable
	BMSVolt (BMS Voltage Control)	Enable
	BMSCurr (BMS Current Control)	BMS




1. Click  in the upper right corner on the home page to enter the password input interface.




2. Enter the correct password (by default 000000) on the input interface, and click  or  to enter the "Setting Options" interface.



3. Slide up and down on the current interface, and click System to enter the system parameter setting interface.



4. Depending on the battery actually used, set **BDCap** and **BType**. After the settings are complete, click **Save** to issue new parameter value.



5. Click **>>** to switch to the "Charge and Discharge Management" interface and set **BCCMode**, **BMSProt**, **BMS**, **BMSVolt** and **BMSCurr**. After the settings are complete, click **Save** to issue new parameters.

Tip

Please go to EPEVER official website to download the currently supported BMS manufacturers and the BMS parameters.

NOTICE

- The inverter/charger will control charging and discharging based on the LCD settings after setting the "BMSCurr (BMS Current Control)" as "Invalid," or the communication between battery and inverter/charger fails.
- Due to the different charging and discharging characteristics and voltage consistency of lithium batteries from different manufacturers, it is necessary for professionals to guide the use of charging and discharging.

2.5.3 Battery voltage control parameters

1) Lead-acid battery voltage control parameters

The parameters are measured in the condition of 48V/25°C.

Battery Type Voltage Control Parameters	AGM	GEL	FLD	User Define
Overvoltage Disconnect Voltage	64.0V	64.0V	64.0V	42.8 - 64V
Charging Limit Voltage	60.0V	60.0V	60.0V	42.8 - 64V
Overvoltage Recovery Voltage	60.0V	60.0V	60.0V	42.8 - 64V
Equalization Charging Voltage	58.4V	--	59.2V	42.8 - 64V
Bulk Charging Voltage	57.6V	56.8V	58.4V	42.8 - 64V
Float Charging Voltage	55.2V	55.2V	55.2V	42.8 - 64V
Bulk Recovery Voltage	52.8V	52.8V	52.8V	42.8 - 64V
Low Voltage Recovery Voltage	50.4V	50.4V	50.4V	42.8 - 64V
Undervoltage Alarm Recovery Voltage	48.8V	48.8V	48.8V	42.8 - 64V
Undervoltage Alarm Voltage	48.0V	48.0V	48.0V	42.8 - 64V
Low Voltage Disconnect Voltage	44.4V	44.4V	44.4V	42.8 - 64V
Discharging Limit Voltage	42.4V	42.4V	42.4V	Read-only

The following rules must be obeyed when setting the Lead-acid battery voltage control parameters.

- A. Overvoltage Disconnect Voltage > Charging Limit Voltage \geq Equalization Charging Voltage \geq Bulk Charging Voltage \geq Float Charging Voltage > Bulk Voltage Recovery Voltage
- B. Overvoltage Disconnect Voltage > Overvoltage Recovery Voltage
- C. Low Voltage Recovery Voltage > Low Voltage Disconnect Voltage \geq Discharging Limit Voltage
- D. Undervoltage Alarm Recovery Voltage > Undervoltage Alarm Voltage \geq Discharging Limit Voltage
- E. Bulk Voltage Recovery Voltage > Low Voltage Recovery Voltage

2) Lithium battery voltage control

Voltage Control Parameters \ Battery Type	LFP		
	48V System		
	LFP15S	LFP16S	User Define
Overvoltage Disconnect Voltage	55.5V	59.2V	42.8 – 64V
Charging Limit Voltage	54.7V	58.4V	42.8 – 64V
Overvoltage Recovery Voltage	54.7V	58.4V	42.8 – 64V
Equalization Charging Voltage	53.5V	57.1V	42.8 – 64V
Bulk Charging Voltage	53.5V	57.1V	42.8 – 64V
Float Charging Voltage	51.0V	54.4V	42.8 – 64V
Bulk Recovery Voltage	49.9V	53.2V	42.8 – 64V
Low Voltage Recovery Voltage	48.7V	52.0V	42.8 – 64V
Undervoltage Alarm Recovery Voltage	48.0V	51.2V	42.8 – 64V
Undervoltage Alarm Voltage	46.5V	49.6V	42.8 – 64V
Low Voltage Disconnect Voltage	43.5V	46.4V	42.8 – 64V
Discharging Limit Voltage	41.2V	44.0V	Read-only

Voltage Control Parameters \ Battery Type	LNCM		
	48V System		
	LNCM13S	LNCM14S	User Define
Overvoltage Disconnect Voltage	55.9V	60.2V	42.8-64V
Charging Limit Voltage	55.2V	59.5V	42.8-64V
Overvoltage Recovery Voltage	55.2V	59.5V	42.8-64V
Equalization Charging Voltage	53.8V	57.9V	42.8-64V
Bulk Charging Voltage	53.8V	57.9V	42.8-64V
Float Charging Voltage	52.0V	56.0V	42.8-64V

Bulk Recovery Voltage	51.0V	55.0V	42.8–64V
Low Voltage Recovery Voltage	48.1V	51.8V	42.8–64V
Undervoltage Alarm Recovery Voltage	46.8V	50.4V	42.8–64V
Undervoltage Alarm Voltage	45.5V	49.0V	42.8–64V
Low Voltage Disconnect Voltage	41.6V	44.8V	42.8–64V
Discharging Limit Voltage	40.3V	43.4V	Read-only

When setting the Lithium battery voltage control parameters, the following rules must be obeyed.

- A. Overvoltage Disconnect Voltage < Over Charging Protection Voltage (BMS Circuit Protection Modules) minus 0.2V
- B. Overvoltage Disconnect Voltage > Charging Limit Voltage ≥ Equalization Charging Voltage ≥ Bulk Charging Voltage ≥ Float Charging Voltage > Bulk Voltage Recovery Voltage
- C. Overvoltage Disconnect Voltage > Overvoltage Recovery Voltage
- D. Bulk Voltage Recovery Voltage > Low Voltage Recovery Voltage > Low Voltage Disconnect Voltage ≥ Discharging Limit Voltage
- E. Undervoltage Alarm Recovery Voltage > Undervoltage Alarm Voltage ≥ Discharging Limit Voltage
- F. Low Voltage Disconnect Voltage ≥ Over Discharging Protection Voltage (BMS Circuit Protection Modules) plus 0.2V

NOTICE

The BMS circuit protection module's voltage control accuracy must be at least $\pm 0.2V$. The [Overvoltage Disconnect Voltage] shall be lower than the protection voltage of the BMS circuit protection module. In contrast, the [Low Voltage Disconnect Voltage] shall be higher. The increased voltage of the [Overvoltage Disconnect Voltage] and the [Low Voltage Disconnect Voltage] is determined by the control accuracy of the BMS circuit protection module.

3 Single Installation

3.1 Attention

- Please read the manual carefully to familiarize yourself with the installation steps.
- Be very careful when installing the batteries, especially flooded lead-acid batteries. Please wear eye protection, and have fresh water available to rinse if contact with battery acid.
- Keep the battery away from any metal objects, which may cause a short circuit of the battery.
- Combustible and harmful gases may come out from the battery during charging. Ensure the ventilation condition is good.
- This inverter/charger is wall-mounted. Consider whether the wall's bearing capacity can meet the requirements.
- Ventilation is highly recommended if mounted in an enclosure. Never install the inverter/charger in a sealed enclosure with flooded batteries! Battery fumes from vented batteries will corrode and destroy the inverter/charger circuits.
- The inverter/charger can work with lead-acid and lithium batteries within its control scope.
- Ensure all switches and breakers are disconnected before wiring. You operate the inverter/charger after checking that all wiring is correct.
- Loose connections and corroded wires may produce high heat that can melt wire insulation, burn surrounding materials, or even cause a fire. Ensure tight connections, use cable clamps to secure cables, and prevent them from swaying in motion.
- Select the system connection cables according to the current density no greater than $5A/mm^2$.
- Do not install the inverter/charger in a harsh environment such as flammable, explosive, or dust accumulative.
- After turning off the switch, high voltage still exists inside the inverter/charger. Do not open or touch the internal devices; wait ten minutes before conducting related operations.
- The input terminal of the battery on the inverter/charger has the function of anti-reverse connection protection, but it is only effective when it is not connected to PV or Utility. Please strictly follow the operation and avoid frequent operations in fault.
- Utility input and AC output are high voltage. Please do not touch the wiring connection.
- When the fan is working, please do not touch it to avoid injury.

NOTICE

- The short-circuit current of the PV array must comply with the "PV Maximum Short-circuit Current" in Chapter 8 [Technical Specifications](#). The reverse connection time should not exceed 5 minutes, avoid frequent operations in fault.
- The PV array must first be connected to a 500VDC or above circuit breaker with arc extinguishing function, and then connected to the inverter/charger. If the PV is reversed, disconnect the external circuit breaker first, and then disconnect the PV array terminal (such as the MC4 terminal) or the PV input terminal of the inverter/charger. Otherwise, an electric arc will be generated, causing damage to the PV array or the inverter/charger.

3.2 Wire size and circuit breaker

The wiring and installation methods must conform to all national and local electrical code requirements.

➤ Recommended PV wire and breaker size

Since the PV output current varies with the PV module's size, connection method, or sunlight angle, the minimum wire size can be calculated by the PV I_{sc} (Max. short circuit current). Please refer to the I_{sc} value in the PV module's specifications. When the PV modules are connected in series, the total I_{sc} equals any PV module's I_{sc} . When the PV modules are connected in parallel, the total I_{sc} equals the sum of the PV module's I_{sc} . The PV array's I_{sc} must not exceed the maximum PV input current. For max. PV input current and max. PV wire size, please refer to the table below:

When two PV arrays are connected independently, the wire and circuit breaker size of each PV array are as follows:

Model	PV Wire Size	Circuit Breaker
HP5542-AH1050P65C	6mm ² /10AWG	2P -- 25A (with arc extinguishing function)

When two PV arrays are connected in parallel, the wire and circuit breaker size are as follows:

Model	PV Wire Size	Circuit Breaker
HP5542-AH1050P65C	10mm ² /7AWG	2P -- 50A (with arc extinguishing function)

NOTICE

When the PV modules are connected in series, the total voltage must not exceed the max. PV open circuit voltage 500V (At minimum operating environment temperature), or 440V (At 25°C).

➤ **Recommended Utility wire size**

Model	Utility Wire Size	Circuit Breaker
HP5542-AH1050P65C	6mm ² /10AWG	2P -- 40A

NOTICE

The utility input has the circuit breaker already; no need to add any more.

➤ **Recommended battery wire and breaker size**

Model	Battery Wire Size	Circuit Breaker
HP5542-AH1050P65C	35mm ² /2AWG	2P -- 200A

NOTICE

The recommended battery breaker size is selected when the battery terminals are not connected to any additional inverter.

➤ **Recommended load wire size**

Model	Load Wire Size	Circuit Breaker
HP5542-AH1050P65C	6mm ² /10AWG	2P -- 40A

NOTICE

- The wire size is only for reference. Suppose a long distance exists between the PV array, the inverter/charger, and the battery. In that case, larger wires shall be used to reduce the voltage drop and improve the system's performance.
- The above wire and circuit breaker sizes are for reference only; please choose a suitable wire and circuit breaker according to the actual situation.

3.3 Mounting the inverter/charger




DANGER

- Risk of explosion! Never install the inverter/charger in a sealed enclosure with flooded batteries!
- Do not install the inverter/charger in a confined area where the battery gas can accumulate.


NOTICE

- The inverter/charger can be fixed to the concrete and solid brick walls, while it cannot be fixed to the hollow brick wall.
- The inverter/charger requires at least 30cm of clearance right and left, and 50cm of clearance above and below.


Step1: Determine the installation location and heat-dissipation space. The inverter/charger requires at least 30cm of clearance right and left, and 50cm of clearance above and below.



Step 2: Fix the wall hanger (included accessory) to the wall, and put the inverter/charger on it.




Step 3: Fix the inverter/charger to the wall hanger with two screws.




3.4 Wiring the inverter/charger

Connect the inverter/charger in the order of ① Grounding > ② Battery > ③ Load > ④ PV array > ⑤ Utility or generator > ⑥ Optional accessories, and disconnect the inverter/charger in the reverse order. The following wiring sequence is illustrated in the appearance of "HP5542-AH0650P65C". For wiring positions of other models, please refer to the actual product appearance.

- No battery mode



- **Battery mode**



1. Grounding


The inverter/charger has a dedicated grounding terminal, which must be grounded reliably. The grounding wire size must be consistent with the recommended load wire size. The grounding connection point shall be as close as possible to the inverter/charger, and the total grounding wire shall be as short as possible.

❌ NO GROUNDING	❌ Do not ground the battery terminals .
	❌ Do not ground the PV terminals.
	❌ Do not ground the AC input L or N terminals between the inverter/charger and the household power distribution cabinet.
✅ GROUNDING	❌ Do not ground the AC output L or N terminals.
	✅ The cabinet case and the PE terminal of AC input and output must be firmly grounded through the earth rail.

2. Connect the battery

NOTICE

- Please disconnect the circuit breaker before wiring and ensure that the leads of "+" and "-" poles are polarity correctly.
- A circuit breaker must be installed on the battery side. Please refer to Subsection [3.2 Wire size and circuit breaker](#) for selection.



3. Connect the AC load




DANGER

High voltage! Electric shock hazard! When wiring the AC load, please disconnect the circuit breaker and ensure that the poles' leads are connected correctly.

NOTICE

- The AC loads shall be determined by the continuous output power of the inverter/charger. The AC load's surge power must be lower than the instantaneous surge power of the inverter/charger, or the inverter/charger will be damaged.
- If inductive loads such as motors, or a bidirectional transfer switch is connected to the AC output terminal, a separate overvoltage and overcurrent protector (VA-Protector) needs to be installed at the AC output terminal.




4. Connect the PV modules

DANGER

- High voltage! Electric shock hazard! The PV array can generate dangerous high-voltage!
- It is forbidden to connect the positive and negative poles of the PV with the ground; otherwise, the inverter/charger will be damaged.
- Disconnect the PV input circuit breaker before wiring, otherwise it may cause equipment damage or electric shock!

NOTICE

Suppose the inverter/charger is used in an area with frequent lightning strikes. In that case, install an external surge arrester at the PV input and utility input terminals is a must.




5. Connect the Utility or generator




- High voltage! Electric shock hazard! The utility input can generate very high voltage. Disconnect the circuit breaker or fast-acting fuse before wiring and ensure that the poles' leads are connected correctly.
- After the utility is connected, the PV and battery cannot be grounded. In contrast, the inverter/charger cover must be grounded reliably to shield the outside electromagnetic interference effectively and prevent the cover from causing electric shock to the human body.

NOTICE

There are various types of oil generators with complex output conditions. It is recommended to use the inverter oil generator. If non-inverter oil generators are used, they must be tested in practice before use.



Dry contact interface: The dry contact interface can turn on/off the generator and is connected parallel with the generator's switch.




Working principle:

When the battery voltage is less than or equal to the Dry Contact ON Voltage, the dry contact is connected. Its coil is energized. The dry contact can drive loads of no more than 125VAC/1A, 30VDC/1A. According to different battery types of the inverter charger, the default values of the Dry Contact ON Voltage and the Dry Contact OFF Voltage are different. Please refer to Subsection [2.5.1 Parameters list](#) for details.

6. Connect optional accessories

• Connect the communication module

Connect the WiFi and Bluetooth modules to the RS485 com. port. End-users can remote monitor the inverter/charger or modify related parameters on the phone APP. Detailed setting methods, refer to APP instruction manual.




Note: For the specific communication modules supported, please refer to the accessories list file.

3.5 Operating the inverter/charger

Step 1: Double-check whether the wire connection is correct.

Step 2: Connect the battery circuit breaker.

Step 3: Turn on the power switch. The LCD will be lit, which means the system running is normal.



NOTICE

- Please connect the battery circuit breaker first. After the inverter/charger normally works, connect the PV array circuit breakers and plug the utility's socket. Otherwise, we won't assume any responsibility for not following the operation.
- The AC output is ON by default after the inverter/charger is powered. Before turning on the power switch, ensure the AC output is connected to loads correctly, and no safety hazard exists.

Step 4: Set parameters by the buttons.

NOTICE

For detailed parameters setting, please refer to Section [2.5 Parameters setting](#).

Step 5: Use the inverter/charger.

Connect the load circuit breaker, the PV array circuit breaker, and plug the utility's socket in sequence. After the AC output is normal, turn on the AC loads one by one. Do not turn on all the loads simultaneously to avoid protection action due to a large transient impulse from the current. The inverter/charger will perform normal work according to the set working mode. See Section [2.4 Real-time data interface](#).

NOTICE

- When supplying power for different AC loads, it is recommended to turn on the load with larger impulse current first. After the load output is stable, turn on the load with smaller impulse current later.
- If the inverter/charger cannot work properly or the LCD/indicator shows an abnormality, please refer to Chapter [6 Troubleshooting](#) or contact our after-sales personnel.


4 Working Mode

4.1 Abbreviation

Abbreviation	Instruction
P _{PV}	PV power
P _{LOAD}	Load power
V _{BAT}	Battery voltage
LVD	Low Voltage Disconnect Voltage
LVR	Low Voltage Recovery Voltage
DP	Discharging Protection SOC
DPR	Discharging Protection Recovery SOC
AUX OFF	Auxiliary Charging OFF Voltage (namely, Utility Charging OFF Voltage)
AUX ON	Auxiliary Charging ON Voltage (namely, Utility Charging ON Voltage)
UAC OFF	Utility Auxiliary Charging OFF SOC
UAC ON	Utility Auxiliary Charging ON SOC
LBACC	Local Battery Available Charging Current
SOC	The battery charging state, which indicates the ratio of the current storage capacity dividing the maximum storage capacity.
PV > BP > BT	Discharging Mode: PV > Bypass > Battery
PV > BT > BP	Discharging Mode: PV > Battery > Bypass
BP > PV > BT	Discharging Mode: Bypass > PV > Battery

4.2 Battery mode

Scenario A: Both PV and Utility are not available.

(A)	Regardless of the input and output sources, the working mode is as follows.	
PV <input checked="" type="checkbox"/>		<p>① Any of the following is satisfied, the battery supplies the load.</p> <ul style="list-style-type: none"> The battery voltage is greater than or equal to the LVR value. The battery SOC is greater than or equal to the DPR value.
Utility <input checked="" type="checkbox"/>	$\begin{matrix} V_{BAT} \geq LVR \\ / SOC \geq DPR \end{matrix} \quad \begin{matrix} \updownarrow \\ V_{BAT} \leq LVD \\ / SOC \leq DP \end{matrix}$	<p>② Any of the following is satisfied, the battery stops supplying the load.</p> <ul style="list-style-type: none"> The battery voltage is lower than or equal to the LVD value. The battery SOC is lower than or equal to the DP value.

NOTICE

- Set the "BCCMode" as "VOL," the working mode is determined by the battery voltage value.
- Set the "BCCMode" as "SOC," the working mode is determined by the battery SOC. Before using the SOC mode, set the "BCCMode" as "VOL" first. Because the battery SOC value will be more accurate after a full charge-discharge cycle in the "VOL" mode.
- For setting the "BCCMode", refer to Subsection [2.5.1 Parameters list](#).


Scenario B: PV is available, but the Utility is not available.

Regardless of the input and output sources, the working mode is as follows.

(B)
PV ☒
Utility ☒




$$P_{PV} > P_{LOAD} \quad \parallel \quad P_{PV} \leq P_{LOAD}$$



$$V_{BAT} \geq LVR \quad \parallel \quad V_{BAT} \leq LVD$$

$$/SOC \geq DPR \quad \parallel \quad /SOC \leq DP$$



① When the PV power is greater than the load power, the PV charges the battery and supplies extra power to the load.



② When the PV power is lower than or equal to the load power, the PV will not charge the battery, the battery will cut in to supply power to the load together with the PV.





③ Any of the following is satisfied, the PV and the battery stop supplying power to the load. The PV charges the battery only.

- The battery voltage is lower than or equal to the LVD value.
- The battery SOC is lower than or equal to the DP value.

Note: When the battery voltage is greater than or equal to the LVR value, or the battery SOC is greater than or equal to the DPR value, the working mode returns to state ②.


Scenario C: Both PV and Utility are available.

(C-1)	PV <input checked="" type="checkbox"/>	Utility <input checked="" type="checkbox"/>	Charging Mode: "Solar"	Discharging Mode: " <u>PV > BP > BT</u> " or " <u>PV > BT > BP</u> "
			 <p> $P_{PV} > P_{LOAD} \parallel P_{PV} \leq P_{LOAD}$ $V_{BAT} \geq LVR / SOC \geq DPR \parallel V_{BAT} \leq LVD / SOC \leq DP$ </p>	<p>① When the PV power is greater than load power, the PV charges the battery and supplies extra power to the load.</p> <p>② When the PV power is lower than or equal to the load power, the PV will not charge the battery, the battery will cut in to supply power to the load together with the PV.</p> <p>③ Any of the following is satisfied, the Utility supplies power to the load and the PV prioritizes charging the battery.</p> <ul style="list-style-type: none"> • The battery voltage is lower than or equal to the LVD value. • The battery SOC is lower than or equal to the DP value.
			<p>Note: When the battery voltage is greater than or equal to the LVR value, or the battery SOC is greater than or equal to the DPR value, the working mode returns to state ②.</p>	
(C-2)	PV <input checked="" type="checkbox"/>	Utility <input checked="" type="checkbox"/>	Charging Mode: "Solar"	Discharging Mode: " <u>BP > PV > BT</u> "
				<p>The Utility supplies power to the load, and the PV charges the battery only.</p>

<p>(C-3)</p> <p>PV <input checked="" type="checkbox"/></p> <p>Utility <input checked="" type="checkbox"/></p>	<p>Charging Mode: "Solar prior"</p>  <p>$P_{PV} > P_{LOAD} \parallel P_{PV} \leq P_{LOAD}$</p>  <p>$V_{BAT} \geq \text{AUX OFF} \parallel \text{SOC} \geq \text{UAC OFF} \parallel V_{BAT} < \text{AUX ON} \parallel \text{SOC} < \text{UAC ON}$</p> 	<p>Discharging Mode: "PV > BP > BT" or "PV > BT > BP"</p> <p>① When the PV power is greater than the load power, the PV charges the battery and supplies extra power to the load.</p> <p>② When the PV power is lower than or equal to the load power, the PV will not charge the battery, the battery will cut in to supply power to the load together with the PV.</p> <p>③ Any of the following is satisfied, the Utility supplies power to the load and charges the battery together with the PV.</p> <ul style="list-style-type: none"> • The battery voltage is lower than or equal to the AUX ON value. • The battery SOC is lower than or equal to the UAC ON value.
<p>(C-4)</p> <p>PV <input checked="" type="checkbox"/></p> <p>Utility <input checked="" type="checkbox"/></p>	<p>Charging Mode: "Solar > Grid"</p>  <p>$P_{PV} > LBACC^* V_{BAT} \parallel P_{PV} \leq LBACC^* V_{BAT}$</p>	<p>Discharging Mode: "BP > PV > BT"</p> <p>① When the PV power is greater than the (LBACC*V_{BAT}), the Utility and PV supply power to the load, and the PV charges the battery at the same time.</p>



$$\begin{aligned} V_{BAT} \geq AOF \\ /SOC \geq UCF \end{aligned} \quad \begin{aligned} V_{BAT} \leq AON \\ /SOC \leq UCO \end{aligned}$$



② When the PV power is lower than or equal to the $(LBACC * V_{BAT})$, the Utility supplies power to the load and the PV charges the battery.

③ Any of the following is satisfied, the Utility supplies power to the load and charges the battery together with the PV.

- The battery voltage is lower than or equal to the AUX ON value.
- The battery SOC is lower than or equal to the UAC ON value.

Note: When the battery voltage is greater than or equal to the **AUX OFF** value, or the battery SOC is greater than or equal to the **UAC OFF** value, the working mode returns to state ②.

(C-5)

Charging Mode: "Solar+Grid"


Discharging Mode: No impact under any mode

PV ☒

Utility ☒




$$\begin{aligned} P_{PV} > LBACC * \\ V_{BAT} \end{aligned} \quad \begin{aligned} P_{PV} \leq LBACC * \\ V_{BAT} \end{aligned}$$










① When the PV power is greater than the $(LBACC * V_{BAT})$, the Utility and PV supply power to the load, and the PV charges the battery simultaneously.


② When the PV power is lower than or equal to the $(LBACC * V_{BAT})$, the Utility and PV charge the battery, and the Utility supplies power to the load.

<p>(C-6)</p> <p>PV <input checked="" type="checkbox"/></p> <p>Utility <input checked="" type="checkbox"/></p>	<p>Charging Mode: "<u>Grid > Solar</u>"</p> 	<p>Discharging Mode: No impact under any mode</p> <p>The Utility supplies power to the load and charges the battery simultaneously.</p>
---	--	---

Scenario D: The PV is not available, but the Utility is available.





<p>(D-1)</p> <p>PV <input checked="" type="checkbox"/></p> <p>Utility <input checked="" type="checkbox"/></p>	<p>Charging Mode: "<u>Solar</u>"</p>  $V_{BAT} \geq LVR \quad \vee \quad V_{BAT} \leq LVD$ $/SOC \geq DPR \quad \vee \quad /SOC \leq DP$ 	<p>Discharging Mode: "<u>PV > BT > BP</u>"</p> <p>① Any of the following is satisfied, the battery supplies the load.</p> <ul style="list-style-type: none"> The battery voltage is greater than or equal to the LVR value. The battery SOC is greater than or equal to the DPR value. <p>② Any of the following is satisfied, the Utility supplies power to the load.</p> <ul style="list-style-type: none"> The battery voltage is lower than or equal to the LVD value. The battery SOC is lower than or equal to the DP value.
<p>(D-2)</p> <p>PV <input checked="" type="checkbox"/></p> <p>Utility <input checked="" type="checkbox"/></p>	<p>Charging Mode: "<u>Solar</u>"</p> 	<p>Discharging Mode: "<u>PV > BP > BT</u>" or "<u>BP > PV > BT</u>"</p> <p>The Utility supplies power to the load.</p>

<p>(D-3)</p> <p>PV ☒</p> <p>Utility ☑</p>	<p>Charging Mode: "Solar > Grid"</p>  <p> $V_{BAT} \geq \text{AUX OFF}$ / $\text{SOC} \geq \text{UAC OFF}$ \parallel $V_{BAT} \leq \text{AUX ON}$ / $\text{SOC} \leq \text{UAC ON}$ </p> 	<p>Discharging Mode: "PV > BT > BP"</p> <p>① Any of the following is satisfied, the battery supplies the load.</p> <ul style="list-style-type: none"> The battery voltage is higher than or equal to the AUX OFF value. The battery SOC is greater than or equal to the UAC OFF value. <p>② Any of the following is satisfied, the Utility supplies power to the load and charges the battery simultaneously.</p> <ul style="list-style-type: none"> The battery voltage is lower than or equal to the AUX ON value. The battery SOC is lower than or equal to the UAC ON value.
<p>(D-4)</p> <p>PV ☒</p> <p>Utility ☑</p>	<p>Charging Mode: "Solar > Grid"</p>  <p> $V_{BAT} \geq \text{AUX OFF}$ / $\text{SOC} \geq \text{UAC OFF}$ \parallel $V_{BAT} \leq \text{AUX ON}$ / $\text{SOC} \leq \text{UAC ON}$ </p> 	<p>Discharging Mode: "PV > BP > BT" or "BP > PV > BT"</p> <p>① Any of the following is satisfied, the Utility supplies power to the load.</p> <ul style="list-style-type: none"> The battery voltage is greater than or equal to the AUX OFF value. The battery SOC is greater than or equal to the UAC OFF value. <p>② Any of the following is satisfied, the Utility supplies power to the load and charges the battery simultaneously.</p> <ul style="list-style-type: none"> The battery voltage is lower than or equal to the AUX ON value. The battery SOC is lower than or equal to the UAC ON value.

(D-5) PV ☒ Utility ☒	Charging Mode: "Solar + Grid" or "Grid > Solar"	Discharging Mode: No impact under any mode The Utility supplies power to the load and charges the battery simultaneously.
		

4.3 No battery mode

Note: Under the no battery mode, the "Charging Mode" and "Discharging Mode" settings will not take effect.

PV ☒ Utility ☒	 <p>$P_{PV} > P_{LOAD} \parallel P_{PV} \leq P_{LOAD}$</p> 	<p>① When the PV power is greater than the load power; the PV supplies power to the load.</p> <p>Note: In this mode, the Utility still keep a minimum power input. When the PV power is lower than the load power, the Utility can replenish the power supply at any time to avoid device shutdown.</p> <p>② When the PV power is lower than or equal to the load power, the PV and the Utility supply power to the load together.</p>
PV ☒ Utility ☒		Only the PV supplies power to the load.
PV ☒ Utility ☒		Only the Utility supplies power to the load.

5 Protections

No.	Protections	Instruction
1	PV limit current/power	When the output current/power of PV array is greater than the PV maximum input current/power of the inverter/charger, the inverter/charger will obtain energy from the whole PV array with the PV maximum input current/power. When the maximum open-circuit voltage of the PV array is less than 360V, excess power (up to 2 times the PV maximum input power of the inverter/charger) can be connected to the solar panel. When the maximum open-circuit voltage of the PV panel input is higher than or equal to 360V, excess power cannot be connected to the PV panel.
2	PV short circuit	When the PV is not charging and short circuit, the inverter/charger is not damaged.
3	PV reverse polarity	The inverter/charger will not be damaged when the PV array is reversely connected, correct the wire connection to resume work. Note: If the maximum open-circuit voltage of the PV array \geq 500V, the inverter/charger will be damaged.
4	Utility input overvoltage	When the utility voltage exceeds the set value of "UOD (Utility Overvoltage Disconnect Voltage)" the utility will stop charging and supplying the load.
5	Utility input undervoltage	When the utility voltage is lower than the set value of "ULVD (Utility Low Voltage Disconnect Voltage)" the utility will stop charging and supplying the load.
6	Battery overvoltage	When the battery voltage goes higher than the "OVD(Overvoltage Disconnect Voltage)," the PV/Utility will stop charging the battery to protect the battery from being over-charged.
7	Battery over-discharge	When the battery voltage goes lower than the "LVD (Low Voltage Disconnect Voltage)," the battery will stop discharging to protect the battery from being over-discharged.
8	Battery reverse polarity	The inverter/charger will not be damaged when the battery is reversely connected, correct the wire connection to resume work.

9	Load output short circuit	<p>The output is turned off immediately in the occurrence of short-circuiting. And then, the output is recovered automatically after a delay time of 5s, 10s, and 15s separately (less than three times recovery within 5 minutes, it will be recounted). The inverter/charger stops working after the 4th protection and can resume working after resetting or restarting.</p> <p>Clear the fault in time because it may damage the inverter/charger permanently.</p> <p>Note: Resetting operation--See Subsection 2.4.6 Error code and then click the Clear button to exit the current fault state and resume normal operation.</p>		
10	Device overheating	<p>When the internal temperature overheats, the inverter/charger will stop charging/discharging.</p> <p>The inverter/charger will resume charging/discharging when the internal temperature is normal.</p>		
11	HP5542-AH1050P65C Inverter overload (no Utility)	$5,665W \leq P < 6,600W$	$6,600W \leq P < 7,700W$	$P \geq 7,700W$
		Protect after 30 seconds	Protect after 10 seconds	Protect immediately
		<p>Note: The output is recovered automatically after a delay time of 5s, 10s, and 15s separately. The inverter/charger stops working after the 4th protection and can resume working after resetting or restarting.</p>		
12	HP5542-AH1050P65C Utility bypass overload (no-Battery mode)	$6,050W \leq P < 6,985W$	$6,985W \leq P < 8,085W$	$P \geq 8,085W$
		Protect after 30 seconds	Protect after 10 seconds	Protect immediately
		<p>Note: The output is recovered automatically after a delay time of 5s, 10s, and 15s separately. The inverter/charger stops working after the 4th protection and can resume working after resetting or restarting.</p>		
13	HP5542-AH1050P65C Utility bypass overload	$8,550W \leq P < 9,485W$	$9,485W \leq P < 1,0585W$	$P \geq 1,0585W$

	(Battery mode)	9,485W	1,0585W	
		Protect after 30 seconds	Protect after 10 seconds	Protect immediately
		Note: The output is recovered automatically after a delay time of 5s, 10s, and 15s separately. The inverter/charger stops working after the 4th protection and can resume working after resetting or restarting.		

6 Troubleshooting

NOTICE

After the inverter/charger is powered on, the meter displays the boot screen all the time (unable to enter the home screen) and the red "RUN" indicator flashes. It means the communication with the inverter/charger is abnormal. When the above fault occurs, check whether the communication cable is disconnected. If not, please contact our after-sales engineer.

6.1 Battery faults

Error code	Fault/Status	Indicator	Buzzer	Solution
Err4	Battery Overvoltage Protection			Disconnect the charging connection, and check whether the battery voltage is too high. Verify if the actual battery voltage matches the rated battery voltage; or check if the "Overvoltage Disconnect Voltage" is inconsistent with the battery specifications. After the battery voltage drops below the set value of "Overvoltage Recovery Voltage", the alarm will automatically be cleared.
Err5	Battery Undervoltage Protection	--	--	Disconnect the loads connection, and check whether the battery voltage is too low. After the battery voltage is charged and restored to above the "Low Voltage Recovery Voltage", it will automatically return to normal, or use other methods to charge the battery.
Err11	Battery Over Temperature			Ensure the battery is installed in a cool and well-ventilated place, check that the battery actual charging and discharging current does not exceed the setting values of "Local Battery Available Charging Current" and "Local Battery Available Discharging Current". It resumes normal work when the battery cools down to below the "Battery Over Temperature Protection Recovery".

Err37	Battery Overcurrent			Check that the battery actual charging and discharging current does not exceed the setting values of "Local Battery Available Charging Current" and "Local Battery Available Discharging Current".
Err39	Battery Cable Disconnected			Check whether the battery connection is normal, and whether the BMS protection occurs.
Err50	Battery Undervoltage Alarm			Check if the battery voltage is lower than the Undervoltage Alarm Voltage.
Err56	Battery Connection Failed			Check if the battery connection is normal and the BMS communication of the lithium battery is normal.

6.2 PV faults

Error code	Fault/Status	Indicator	Buzzer	Solution
Err15	PV1 Overvoltage	PV indicator solid red	Intermittent beeps	Check if the PV open-circuit voltage is higher than "Overvoltage Protection Voltage". The alarm is released when the PV open-circuit voltage is below "Overvoltage Recovery Voltage".
Err17	PV1 Overcurrent	PV indicator solid green	--	Turn off the inverter/charger first, wait for 5 minutes and then turn on the inverter/charger to check if it resumes normal. If it is still abnormal, please contact our technical support.
Err18	PV2 Overvoltage	PV indicator solid red	Intermittent beeps	Check if the PV open-circuit voltage is higher than "Overvoltage Protection Voltage". The alarm is released when the PV open-circuit

				voltage is below "Overvoltage Recovery Voltage".
Err20	PV2 Overcurrent	PV indicator solid green	--	Turn off the inverter/charger first, wait for 5 minutes and then turn on the inverter/charger to check if it resumes normal. If it is still abnormal, please contact our technical support.
Err30	PV HARD FAULT (PV Hardware Fault)			
Err43	PV1TSD (PV1 Temperature Sensor Disconnected)			
Err52	PV1 PCTO (PV1 Pre-charge Timeout)	PV indicator solid green	--	Turn off the inverter/charger first, wait for 5 minutes and then turn on the inverter/charger to check if it resumes normal. If it is still abnormal, please contact our technical support.
Err53	PV2 PCTO (PV2 Pre-charge Timeout)			

6.3 Inverter faults

Error code	Fault/Status	Indicator	Buzzer	Solution
Err2	Inverter Output Overcurrent	LOAD indicator solid red	Intermittent beeps	Check if the load actual power exceeds the "Inverter Rated Power (see Chapter 8 Technical Specifications)," disconnect the load completely and turn off the inverter/charger. Wait 5 minutes and then turn on the inverter/charger to check if it resumes normal. If it is still abnormal, please contact our technical support.
Err7	Inverter Output Overvoltage	LOAD indicator solid red	Intermittent beeps	Check whether the inverter output is higher than the "Over Voltage Protection" (See 2.4.4 Load , click Fun to enter the "Setting Parameters To Display"

				<p>page to view the value of this parameter).</p> <p>Disconnect the load completely and turn off the inverter/charger. Wait 5 minutes and then turn on the inverter/charger to check if it resumes normal. If it is still abnormal, please contact our technical support.</p>
Err10	Inverter Over Temperature	--	--	<p>Ensure the inverter/charger is installed in a cool and well-ventilated place.</p>
Err22	Inverter Hardware Overvoltage	--	--	<p>Disconnect the load completely and turn off the inverter/charger. Wait 5 minutes and then turn on the inverter/charger to check if it resumes normal. If it is still abnormal, please contact our technical support.</p>
Err23	Inverter Hardware Overcurrent			
Err32	Inverter Voltage OFFSET Error			
Err35	Inverter Current OFFSET Error	--	--	<p>Disconnect the load completely and turn off the inverter/charger. Wait 5 minutes and then turn on the inverter/charger to check if it resumes normal. If it is still abnormal, please contact our technical support.</p>
Err45	Inverter Temp Sensor Disconnected	LOAD indicator solid green	--	<p>Turn off the inverter/charger. Wait 5 minutes and then turn on the inverter/charger to check if it resumes normal. If it is still abnormal, please contact our technical support.</p>

Err49	Inverter Output Undervoltage	LOAD indicator solid red	Intermittent beeps	Check if the load actual power exceeds the "Inverter Rated Power (see Chapter 8 Technical Specifications)," disconnect the load completely and turn off the inverter/charger. Wait 5 minutes and then turn on the inverter/charger to check if it resumes normal. If it is still abnormal, please contact our technical support.
-------	------------------------------	--------------------------	--------------------	---

6.4 Utility faults

Error code	Fault/Status	Indicator	Buzzer	Solution
Err8	Utility Overvoltage	GRID indicator solid red	Intermittent beeps	Check if the utility voltage is exceeds the "Utility Overvoltage Disconnect Voltage", then disconnect the AC input and turn off the inverter/charger. Wait 5 minutes and then turn on the inverter/charger to check if it resumes normal. If it is still abnormal, please contact our technical support.
Err9	Utility Overcurrent	GRID indicator solid red	Intermittent beeps	Check if the load actual power exceeds the "Inverter Rated Power (see Chapter 8 Technical Specifications)," disconnect the load completely and turn off the inverter/charger. Wait 5 minutes and then turn on the inverter/charger to check if it resumes normal. If it is still abnormal, please contact our technical support.
Err25	Utility Undervoltage	GRID indicator solid red	--	Check if the utility voltage is lower than the "Utility Low Voltage Disconnect Voltage", disconnect the utility input and

				turn off the inverter/charger. Wait 5 minutes and then turn on the inverter/charger to check if it resumes normal. If it is still abnormal, please contact our technical support.
Err28	Utility Pre-charge Timeout	GRID indicator solid green	--	Check if the utility frequency is between the "Utility Underfrequency Disconnect Frequency" to "Utility Overfrequency Disconnect Frequency" disconnect the utility input and turn off the inverter/charger. Wait 5 minutes and then turn on the inverter/charger to check if it resumes normal. If it is still abnormal, please contact our technical support.
Err29	Utility Relay Adhesion	GRID indicator solid green	--	
Err31	Utility Frequency Error	GRID indicator solid red	Intermittent beeps	

6.5 Load faults

Error code	Fault/Status	Indicator	Buzzer	Solution
Err33	Load Current OFFSET Error	--	--	Disconnect the load completely and turn off the inverter/charger. Wait 5 minutes and then turn on the inverter/charger to check if it resumes normal. If it is still abnormal, please contact our technical support.
Err48	Load Over Load	LOAD indicator solid red	Intermittent beeps	
Err55	Overload Lockdown	LOAD indicator solid red	Intermittent beeps	

6.6 Other faults for single inverter/charger

Error code	Fault/Status	Indicator	Buzzer	Solution
Err0	DC Bus Overvoltage	--	--	Turn off the inverter/charger. Wait 5 minutes and then turn on the inverter/charger to check if it resumes normal. If it is still abnormal, please contact our technical support.
Err6	DC Bus Undervoltage			
Err12	Ambient Over Temperature	--	--	Ensure the inverter/charger is installed in a cool and well-ventilated place.
Err21	Battery or Bus Hardware Overvoltage	--	--	Turn off the inverter/charger. Wait 5 minutes and then turn on the inverter/charger to check if it resumes normal. If it is still abnormal, please contact our technical support.
Err24	High Volt Bus Hardware Overcurrent			
Err36	High Volt Bus Current Abnormal			
Err38	Boost Drive Error			
Err40	Auxiliary Power Supply Abnormal			
Err42	Environment Temp Sensor Disconnected	--	--	Turn off the inverter/charger. Wait 5 minutes and then turn on the inverter/charger to check if it resumes normal. If it is still abnormal, please contact our technical support.
Err46	Low Temperature Charging Limit	--	--	Check whether the ambient temperature is lower than the set "Low Temperature Stop Charging Temperature" and "Low Temperature Stop Discharging Temperature".
Err47	Low Temperature Discharging Limit			
Err54	EEprom Abnormal	--	--	Turn off the inverter/charger. Wait 5 minutes and then turn

				on the inverter/charger to check if it resumes normal. If it is still abnormal, please contact our technical support.
--	--	--	--	---

6.7 BMS faults

Error code	Fault/Status	Indicator	Buzzer	Solution
Err66	BMS Overvoltage	--	--	Check the BMS communication status or BMS setting parameters.
Err68	BMS Charging Temp Abnormal			
Err69	BMS Undervoltage			
Err71	BMS Discharging Temp Abnormal			
Err74	BMS Communication Failure			

7 Maintenance

The following inspections and maintenance tasks are recommended at least twice yearly for best performance.

- Make sure no block on airflow around the inverter/charger. Clear up dirt and fragments on the radiator.
- Check all the wired cables to ensure insulation is not damaged for serious solarization, frictional wear, dryness, insects or rats, etc. Repair or replace some wires if necessary.
- Check and confirm that LED or LCD is consistent with the required. Pay attention to any troubleshooting or error indication. Take necessary corrective action.
- Confirm that all the terminals have no corrosion, insulation damage, high temperature, or burnt/discolored sign; tighten terminal screws to the suggested torque.
- Check for dirt, nesting insects, and corrosion. If so, clear up in time.
- Check and confirm that the lightning arrester is in good condition. Replace a new one in time to avoid damaging the inverter/charger and other equipment.



DANGER


Electric shock hazard! Make sure that the power supply of the inverter/charger is disconnected when performing the above operations, and wait for 10 minutes for the power in the capacitor to be discharged before performing the corresponding checks or operations.

8 Technical Specifications

Model	HP5542-AH1050P65C
Utility Input	
Utility Input Voltage	176VAC to 264VAC (Default) 90VAC to 285VAC (Configurable)
Utility Input Frequency	45Hz to 65Hz
Maximum Utility Charging Current	100A
Switch Response Time	Inverter to Utility: 10ms Utility to Inverter (when the load power is higher than 100W): 20ms
Inverter Output	
Inverter Rated Power (@30°C)	5,500W
3-second Transient Surge Output Power	8,500W
Inverter Output Voltage	220/230VAC \pm 3%
Inverter Frequency	50/60Hz \pm 0.2%
Output Voltage Waveform	Pure sine wave
Load Power Factor	0.2 – 1 (VA \leq Rated output power)
THDu (Total Harmonic Voltage Distortion)	\leq 3% (48V resistive load)
Maximum Load Efficiency	91%
Maximum Inverter Efficiency	94%
Solar Controller	
PV Maximum Open-circuit Voltage	500V (At minimum operating environment temperature) 440V (At 25°C)
MPPT Voltage Range	85V to 400V

Number of MPPTs	2
PV Maximum Input Current	Two ways, $2 \times 15\text{A}$
PV Maximum Input Power	$2 \times 3,000\text{W}$
MPPT Maximum efficiency	$\geq 99.5\%$
Battery	
Battery Rated Voltage	48VDC
Battery Work Voltage Range	43.2VDC to 64VDC
Battery Maximum Charging Current	100A
Others	
No-load Losses	$\leq 1.2\text{A}$
	Test condition: Utility, PV and Load are disconnected, AC output is ON, fan stops, @48V input
Standby Current	$\leq 0.8\text{A}$
	Test condition: Utility, PV and Load are disconnected, AC output is OFF, fan stops, @48V input
Work Temperature Range	-20°C to $+55^{\circ}\text{C}$ ($> 35^{\circ}\text{C}$ derating) ⁽¹⁾
Storage Temperature Range	-25°C to $+60^{\circ}\text{C}$
Enclosure	IP65
Relative Humidity	$< 100\%$ (N.C.)
Altitude	$< 4,000\text{m}$ ($> 2,000$ meters derating)
Mechanical Parameters	
Dimension (L × W × H)	545mm × 428mm × 248mm
Mounting Size (L × W)	350mm × 130mm
Mounting Hole Size	Φ 10mm
Net Weight	25.4Kg


(1) The graph showing the variation of output power with environment temperature is as follows.



9 Dimensions

Model: HP5542-AH1050P65C

Unit: mm



10 Appendices

10.1 Appendix1 Abbreviations index



Interface	Abbreviations	Full Name
Solar Setting Parameter	OVP	Overvoltage Protection
	OVPR	Overvoltage Protection Recovery
	OTP	Over Temperature Protection
	OTPR	Over Temperature Protection Recovery
Voltage Control Strategy	OVD	Overvoltage Disconnect Voltage
	CLV	Charging Limit Voltage
	OVR	Overvoltage Recovery Voltage
	ECV	Equalization Charging Voltage
	BCV	Bulk Charging Voltage
	FCV	Float Charging Voltage
	BVR	Bulk Voltage Recovery Voltage
	LVR	Low Voltage Recovery Voltage
	UVWR	Undervoltage Alarm Recovery Voltage
	UVW	Undervoltage Alarm Voltage
	LVD	Low Voltage Disconnect Voltage
	DLV	Discharging Limit Voltage
	AUX OFF	Auxiliary Charging OFF Voltage
	AUX ON	Auxiliary Charging ON Voltage
SOC Control Strategy	FCP	Full Charge Protection SOC
	FCPR	Full Charge Protection Recovery SOC
	LPAR	Low Power Alarm Recovery SOC
	LPA	Low Power Alarm SOC


	DPR	Discharging Protection Recovery SOC
	DP	Discharging Protection SOC
	UAC ON	Utility Auxiliary Charging ON SOC
	UAC OFF	Utility Auxiliary Charging OFF SOC
	Set SOC	Set SOC
Utility Setting Parameter	UOD	Utility Overvoltage Disconnect Voltage
	UOR	Utility Overvoltage Reconnect Voltage
	ULVD	Utility Low Voltage Disconnect Voltage
	ULVR	Utility Low Voltage Reconnect Voltage
	UOF	Utility Overfrequency Disconnect Frequency
	UFD	Utility Underfrequency Disconnect Frequency
Load Setting Parameter	INVOVL	Inverter Output Voltage Level
	INVOFR	Inverter Output Frequency Range
	Load CL	Load Current Limit
	INVOP	Inverter Overvoltage Protection Voltage
	INVOPR	Inverter Overvoltage Protection Recovery Voltage
	TempUL	Temperature Upper Limit
	TempULR	Temperature Upper Limit Recovery
Battery Basic Properties	Status	Battery Status
	BDCap	Battery Design Capacity
	BType	Battery Type
	BRV	Battery Voltage
	LBACC	Local Battery Available Charging Current
	LBADC	Local Battery Available Discharging Current
	BECT	Battery Equalization Charging Time
	BECD	Battery Equalization Charging Date


	BBCT	Battery Bulk Charging Time
	BTCC	Battery Temperature Compensation Coefficient
Advanced Battery Properties	Li PROT	Lithium Battery Protection
	LTSchrg	Low Temperature Stop Charging Temperature
	LTSDischrg	Low Temperature Stop Discharging Temperature
	BATT OTP	Battery Over Temperature Protection
	BATT OTPR	Battery Over Temperature Protection Recovery
	Chrg	Charging
	Dischrg	Discharging
	PCUP	Phase Current Unbalance Protection
	INVPSet	Inverter Phase Setting
	UCD	Unbalanced Current Difference
Charge and Discharge Management	BACC	Battery Available Charging Current
	BADC	Battery Available Discharging Current
	UACC	Utility Available Charging Current
	CMode	Charging Mode
	DMode	Discharge Mode
	ACmode	AC Input Mode
	PVMode	PV Mode
	BCCMode	Battery Charging Control Mode
	BMSProt	BMS Protocol
	BMS	BMS Enable
	BMSVolt	BMS Voltage Control
	BMSCurr	BMS Current Control
	BMSFail	BMS Fail Action



Local Parameters	LCD BRT	LCD Brightness
	TODelay	Idle Timeout Delay
	LCDSBRT	Standby LCD Brightness
	SOT	Screen Off Time
	Com ID	Communication ID
	Com BPS	Communication Baud Rate
	DCT ON	Dry Contract ON Voltage
	DCT OFF	Dry Contract OFF Voltage
	Switch BMS	Switch BMS
	HRI	History Record Interval
Others	Wireless	Wireless
	RTU POWER	RTU POWER
	Screen Timeout	Screen Timeout
	Parameter Rest	Parameter Rest
	Low Power Mode	Low Power Mode
	Manual Equalizer	Manual Equalizer
	DC Source Characteristic	DC Source Characteristic
	Initializing Records	Initializing Records
	Clear Statistical Power	Clear Statistical Power

10.2 Appendix 2 Battery state instruction





1. Click the battery icon  on the home page to enter the battery real-time data interface.

2. Touch the  to enter the battery state interface.



3. The first page shows the "Battery State."

4. Click **Down** button to shows the "Cell State" on second page.



5. Click **Down** button to shows the "Cell State And Other" on third pages.

6. Click **Down** button to shows the "Other" on forth pages.

The detailed data of each interface is as follows:

LCD	English Display	Description
Battery State	Charging protection	Green means this state has not occurred, red means this state has occurred. After showing red, the inverter/charger turns off charging.
	Discharge protection	Green means this state has not occurred, red means this state has occurred. After showing red, the inverter/charger turns off discharging.
	Communication Error	The communication between BMS-Link and lithium battery BMS fails (such as wrong protocol selection, mismatched communication cables, etc.). Green means this state has not occurred, red means this state has occurred. After showing red, the inverter/charger turns off charging and discharging.
	Other protection	Green means this state has not occurred, red means this state has occurred. After showing red, the inverter/charger turns off the charging and discharging.
	Charge overtemperature	Green means this state has not occurred, red means this state has occurred. After showing red, the inverter/charger turns off charging.
	Discharge overtemperature	Green means this state has not occurred, red means this state has occurred. After showing red, the inverter/charger turns off discharging.
	Full of requests	Green means this state has not occurred, red means this state has occurred.
	Forced charge	
	Discharge Enable	Green means discharging is enabled. Red means discharging is disabled. After showing red, the inverter/charger turns off discharging.
	Charge Enable	Green means charging is enabled. Red means charging is disabled. After showing red, the inverter/charger turns off charging.

Cell State	1 Normal to 14 Normal	If it is detected that the current single battery cell is normal or there is no battery cell, it will display green; if the current battery cell is abnormal, the display will turn red.
Cell State And Other	15 Normal to 16 Normal	The abnormal status of a single battery cell includes: Undervoltage alarm, Overvoltage alarm, Undervoltage protect, Overvoltage protect, and Cell detection. After reading the undervoltage alarm or protection of the single cell, the inverter/charger turns off discharging. After reading the overvoltage alarm or protection of the single cell, the inverter/charger turns off charging.
	MOS Temperature State	Normal display is green, abnormal display is red. Abnormal status includes: High temperature alarm, Low temperature alarm, High temperature protect, Low temperature protect, NTC fault. The inverter/charger turns off charging and discharging.
	Environment Temperature State	
	Equalization Temperature State	
	Cell Temperature State	
Other	Pack Voltage State Undervoltage alarm	Normal display is green, abnormal display is red. Abnormal status includes: Undervoltage alarm, Overvoltage alarm, Undervoltage protect, Overvoltage protect. After reading the BMS under-voltage alarm or protection, the inverter/charger turns off discharging. After reading the BMS over-voltage alarm or protection, the inverter/charger turns off charging.
	Pack Current State Overcharge alarm	Normal display is green, abnormal display is red. Abnormal status includes: Overrelease alarm, Overcharge alarm, Overdischarge protection, Overcharge protection. After reading the BMS over-discharge alarm or protection, the inverter/charger turns off discharging. After reading the BMS overcharge alarm or protection, the inverter/charger turns off charging.

Any changes without prior notice! Version number: V1.1



HUIZHOU EPEVER TECHNOLOGY CO., LTD.

+86 - 752-3889706

info@epever.com

www.epever.com